

P/N	Description	P/N	Description
572B101	A-2 Technology	600D105A-B	Acer Ergo Keyboard Fcc:JVPERGO Numeric Pad Separate unit
466C112	ABB #6053T Universal Keyboard	610D104	Acer 6511-Q Fcc:JVP6511Q W/Win Keys
297C135	ABB(ASEA) 47DSIH80	611D105	Acer 6511-Q (Euro) Fcc: JVP6511Q w/Win Keys
87D129	ABB Advant DCS	664D104	Acer 6511-M Fcc: JVP6511M (also Tangent)
413C90	Abbott Axsym Keyboard	658D86	Acer 7100T Fcc:HLZ970T (also Texas Instrument)
776C102	Ace Natural Ergo Kybrd(also Addison, PC Concepts, Chicony)	879D105	Acer 6512-P Fcc:JVP6511-P "7" enter
288D104	Ace Model F-21 W/ Win keys Fcc :GOGAPC-21	139E107	Acer 6511-TA, back L-enter
229D105	Ace Model F-21, F-21J w/Win keys Fcc: GOGAPC-21 (single left shift key)	920D108	Acer 6512-TA (Euro) "7" enter
441D104	Ace F-21,F21D,fcc:GOGAPC-21 win/curve spacebar	929D108	Acer 6512-VA (Euro) "7" enter
457D105	Ace GOGAPC-21 W/Win keys, Single right shift key Curve spacebar, back-L enter	961D105	Acer 6512-V (Euro) "7" enter
756D105	Ace F-21J(X) Fcc:GOGAPC21, Back- L enter	93E119	Acer 6512-VM (Euro) Multimedia "7"enter
792D109	Ace F21XQ Fcc:GOGAPC-F-21 (also Softkey,APC)	951D108	Acer 6512-HA (Euro) "7" enter
193E125	Ace F21GQ, Fcc:GOGAPC21, "7" enter	966D86	Acer #720 Fcc: 722itx W/win, rec enter,glidepoint
789C85	Acekey ACK-500 Mini Keyboard (also Unitek)	29E87	Acer WIL-172U, Fcc:JVPWIL, Windows, mousebutton
245D88	Acekey ACK-595 w/Win keys Fcc:L2BACEKEY595	86E86	Acer Travelmate 602TER, M/N 1902, Glidepoint
790C101	Acekey ACK-200 Fcc:H2UACEKEY200 (also Unitek)	89E86	Acer Travelmate 507DX, M/N 1901, Glidepoint
791C101	Acekey ACK-700 Fcc:L2ACEKEY700 (also Unitek)	452E89	Acer Travelmate C100 series, M/N MS2101, Rec enter
998D102	Acekey ACK-700 UKDin (Euro) Fcc:L2ACEKEY700	153E104	Acer 6511CX, back-L enter
415D108	Acekey ACK360/220 Fcc:L2BACEKEY220 (also Cirque)	154E105	Acer 6511CX (Euro), "7" enter
359D105	Acekey ACK-310 Fcc: L2BACEKEY310 (Also Supermac)	190E118	Acer 6512-UV (Euro), Multimedia, "7" enter
640D90	Acekey ACK-540 Fcc: L2BACEKEY540	261E112	Acer 6512-G (Euro), A7" enter, Multimedia
814D105	Acekey ACK-210 Fcc: L2BACEKEY210	262E108	Acer 6512-X (Euro), A7" enter, Multimedia
807D104	Acekey ACK-295 Fcc: L2BACEKEY295 (also Netier)	293E117	Acer 6511-UV, back-L enter, Multimedia
734D105	Acekey ACK-295 (Euro) Fcc:L2BACEKEY295 w/Win Keys "7" enter key	538E108	Acer 6512-HK (Euro) A7" enter
659D104	Acekey KB9000 Fcc:LFCACKEY1 (also KTX)	608E107	Acer 6511WA, Back-L enter, 3keys above arrows
789D109	Acekey KB9000(E) Fcc:LFACEKEY1	640E90	Acer Travelmate 800, model ZG15
26E107	Acekey 260A Fcc:L2BACEKEY260A, 3 Multimedia, Curve spacebar, back-L enter (also Logitech)	643E110	Acer 6512-UY (Euro)
62E88	Acekey ACK-550 Fcc:L2BACEKEY550, w/Windows	1986B104	Acer 6511-XA
204E104	Acekey ACK-700, back-L enter	846E91	Acer 4151 Laptop
214E91	Acekey ACK-570,ACK-571, Wireless keybd., Rec enter	900E115	Acer KU-0355
291E104	Acekey K2726, Back-L enter, c/c reader (also Unitech)	810B101	Acros 200/386SX(also Acer)
392E108	Acekey AT EZ-9000 (Euro), A7" enter, w/windows	382C101	Acros 6311-B (also Acer)
517E105	Acekey ACK-720 (Euro), A7" enter, (also Unitech)	730B102	Actebis K104 (Euro) (also Monterey,Amax)
637E109	Acekey ACK-730, Glidepoint, Back-L enter	511E108	Acteck AT-9900-1 (Euro) Fcc: ZDK8QL6908W
725E107	Acekey ACK-270A, back-L enter, Curve Spacebar (Also Logitech)	512E126	Acteck AT-EZ8810 (Euro)
854E107	Acekey 201A	772E136	Acteck EZ-7000, AT-7000XP, (Euro), Multimedia
908E105	Acekey 206UA (Euro), 3 hot buttons, A7" shape enter	773E108	Acteck AT-9910 (Euro)
73B101	Acer Data 101/710/910/915/1100/1030, 6311-K (8x19.5) model APC-HA410 (also NEC,Multitech,Cannon, Stone System,Delta Gold,Texas Instrument, Data General) Fcc: GQ87EE6011	774E129	Acteck EZ-9930, AT-9930 (Euro), Multimedia
810B101	Acer 6011/6311/6511/6511-N, KB101 (18 X7.5), Fcc: GQ86311-K, Rec. Enter (also Acros)	424C101	Addison KB5311 (also Chicony,Compudyne)
645B102	Acer MF II 102 Germany 6312-K, Fcc:GQ86311-K (Euro) (also Data General)	720C92	Addison KB5591 w/trackball FCC:E8HKB5591 (also Chicony)
961A97	Acer 900 MKO22035641 (also Multitech)	776C102	Addison KB-7001 FCC:LIAKB7000 (also Ace, PC Concepts, Chicony)
157C102	Acer 6012(Euro)	52A72	Adds Viewpoint A-2 old Style w/Raised border
324C101	Acer 6311G Fcc:GQ86311G	378A81	Adds Viewpoint A-2 New Version
382C101	Acer 6311-B (also Acros)	382A98	Adds Viewpoint 60
609C101	Acer 6511-T Fcc:JUP-6511-T	623A99	Adds Viewpoint 60(+) Color
675C101	Acer 6311K Fcc:JUP6311 ("L" shaped enter)	634A98	Adds Viewpoint 60(+) Color(New Larger Shift Key)
482C82	Acer V386SL Laptop Fcc:GQ8V386SL	175B87	Adds 78
494C102	Acer 6512-T (Euro) Fcc:JVP6511-T	764A83	Adds 1010
178D105	Acer 6512-TW (Euro) w/Win keys	767A100	Adds 2020
516C101	Acer 6311-W ,6311-KE (also Smith Corona)	8IB100	Adds/NCR 4940
15D101	Acer 6511-H Rec. Enter Fcc: JVP-6511-H	209B112	Adds 3220
303D104	Acer 6511-HW Fcc:JVPKBS-WIN rec enter	538C101	Adds 4000 P/N 006-9801788, 119967-001, Fcc:AQ6ZRT687XT "L" Shaped Enter Key (also Esprit, Hitek)
134D105	Acer 6511-HW (EURO) W/Win keys Fcc:JVP6511H	70C106	Adds PC+/4000(also NCR,Hitek,Tandem)
97D101	Acer 6511-K11 Fcc:JVP6511 "L" shaped enter	70C106	Adds TS-530 (also Hitek,NCR,Hitek)
121D104	Acer 6511TW w/Win keys Fcc:JVPKBS-WIN "L" Shaped Enter Key	898C106	Adds 120049-001 #006-980149,RT665DT (also Hitek)
349D105	Acer 6312KW w/Win(Euro) Fcc:JVPKBS-WIN	13D105	Adds Ansi 598-004308
279D104	Acer 6311TW/6511HW "L"enter Fcc:JVPKBS-WIN	129C105	Adds Ansi P/N 2970-9003-9000 (also NCR)
281D104	Acer 6311KW/6511KW Win "L" Fcc:JVPKBS-WIN	478C101	Adds 598-0010481 M/N 121674-001 (also AST,Compaq,Hitek,NEC,NCD)
266D84	Acer Acenote Light 350PCX(PORT) Fcc:HLZ350P	767B108	Adds 598-001-2208, P/N297-9003-9000, 598-0013684 (also Dec)
475D104	Acer 6514 Fcc:JVP6511	285E101	Adds ASCII 598-0011717, rec enter, (also Wyse)
521D105	Acer 6512-C W/Win(EURO) Fcc: JVPKBS-WIN	38D106	Adesso AEK606 ERGO Fcc:KJXKB-205
587D104	Acer 6311-C Fcc: JVPKBS-WIN W/WIN KEYS	69D103	Adesso AEK-202 Propoint w/mousebutton Fcc:GM8MAK105TB
598D104	Acer 6511AW Fcc: JVPKBS-Win W/ Win	71D105	Adesso AEK-305 Softouch Plus, Fcc:KJXKB205
		72D107	Adesso AEK806 Truform ERGO Fcc:KJXEKB105MJ
		289D108	Adesso EKB104MJ(MCK-108P) TRUFORM ERGO w/ trackball Fcc:KJXEKB104MJ

P/N	Description	P/N	Description
290D107	Adesso PCK-308T TRUFORM ERGO w/glidepad Fcc:KJXEKB104MJ	35B101	ALR 386 (also Maxiswitch, Everex, Gateway, Opus, Easy Data, Avtech, Texas Microsystems)
291D108	Adesso AEK-906T TRUFORM ERGO w/glidepoint Fcc:KJXEKB105MJ	477C101	ALR RT-101(+) 119135-001 rev.B 119637 Fcc:AQ6ZG-RT-667XT
292D105	Adesso PCK208A TRUFORM MCK208 Fcc:KJEKB104MJ	286C101	Alton SK-8843-IU (also Liteon)
293D105	Adesso PCK301 NUFORM ERGO Fcc:GM8EKB804	385A101	Altos III/386/Altos V (also Wyse)
294D107	Adesso PCK303T NUFORM ERGO w/Glidepoint Fcc:GM8EKB804	840A101	Altos VII (also Wyse)
295D106	Adesso AEK501 NUFORM ERGO "MAC" version Fcc:KJXEKB105MJ	730B102	Amaz (also Monterey, Actebis)
310D108	Adesso AEK503T Mac NUFORM ERGO w/touchpad Fcc:KJXEKB105MJ	841A102	Amdek 102 Key (also Wyse, Arnet)840358-16
296D108	Adesso PCK-302P (EKB-804MJ) w/touchpoint Fcc:KJXEKB804MJ	803E91	Amino JKWL03
514D105	Adesso KB405 Fcc:KJXKB405	520A105	Amkey 105 Switch
346E109	Adesso WKB-120, back-L enter, Glidepoint	799B80	Amkey Trackball #93-002
347E110	Adesso Trueform EKB-2000TP, PCK-308T, Fcc: KJXEKB104MJ	140C130	Amkey 130-0001
348E108	Adesso Trueform EKB-2000, MCK208, Fcc:KJXEKB104MJ	357E70	Amkey model 70-0017
529E101	Adesso MCK-91 (also Ortek)	478A86	Ampex 210/210(+)
741E109	Adesso KB2101PUSG	646A105	Ampex 220 (also Phillips)
802E88	Adesso AKB901	570A111	Ampex 230 (also Televideo)
853E124	Adesso EL-9805PB illuminated multimedia keyboard	82B106	Ampex 230(+)/219/232/270/280 (also Alpha Micro)
154C108	ADP 507CT (108 keys)	812A85	Amstrad 1512 P.C.1640
151C101	ADP 505MT/507CT	867B101	Amstrad PPC 512
03C107	ADP 502MT/M22	591A94	Ann Arbor V269
774B101	ADP 503/504MT	158A77	Ann Arbor 400E
711B101	ADP APC920MXT	797B101	Anser Research DFK121/171/191 (also Datacomp, Aser, Diamond Flower)
986C101	ADP 508VT (also Chicony)	111D104	Ancer KB8000 KF191 w/Windows Keys FCC:KM988KKB88191
848B101	AEG Olympia EO3601(also Keytronics)	553D104	AOPEN KB850P P/N 90.0007.21 (Also Keytronics)
850D88	Ager Model# 862, Fcc:FMA862, Multimedia Laptop	14E107	AOPEN KB898AS Ergo, Windows, back-L enter KBWIN98, (also Monterey)
338B101	AGI 386/486 (also Keytronics, Premier, Datamaxx, Mitsubishi, Goldstar, Spear Technologies, Gateway)	971D108	AOPEN KB898AS (Euro) Ergo, Windows, "7" enter
509C101	AIC-KNS Keyboard	188E123	AOPEN KB-SP910PS2 (Euro), Multimedia, "7" enter
157D101	AIC-KNS Keyboard (Lower Keys than 509C101)	279E107	AOPEN KB855,KB-858 back-L enter (also Monterey) 3 keys above directional keys
662D104	AIC Cybernet Keyboard	463E107	AOPEN KB-858, 90.00029.58B, Rect. Enter
253B84	AID 84 Switch, AID-3	301E107	AOPEN #90-00007.A01, Rec enter, 3 keys above arrows
437D84	AID 84 Switch (same as above but flaps under)	599E107	AOPEN 90.00029.868 (also Monterey)
736B82	AID-3 (KURT CHECK XT)	585E107	AOPEN 90.00029.823 Back-L enter
918B101	AID EKT-101(also Kodak)	913B101	APC 101
423C102	AID EKT-102 (Euro)(also Kodak)	258C101	APC 101 (notepad)(also Fame) Fcc:GOG3YL-5539
712B59	AID MK057	40D101	APC-21 Fcc:GOGAPC-21 (also DTK)
94E109	AIMC SK1689(Euro),Fcc:GYUR89SK,"7" enter, (also Compaq, Dell, Liteon)	309D101	APC F-21 GOGAPC-21 (also PC Concepts)
404E107	Alaska Scorpius KII+ (also Qtronix)	441D104	APC F-21,21D Fcc:GOGAPC-21 W/Win curve spacebar
241E108	Alaska Scorpius KII+ (Euro), A7" enter (also Qtronix)	457D105	APC F-21 Fcc:GOGAPC-21 W/Win, Single right shift key, Curve Spacebar
296E115	Alaska SK2690, P/N KK2690R2E, (Euro), A7" enter Multimedia	288D104	APC F-21 Fcc:GOGAPC-21 W/WIN (ALSO ACE)
619E109	Alaska KB-AK2002R, Fcc:IZITK-105M (also Professional)	229D105	APC F-21, F-21J, w/WIN KEYS,FCC:GOGAPC-21 Single left shift key
712E125	Alaska Multimedia keyboard Fcc:IZITK-105M (also Professional)	711B101	APC 920 MXT(also Hitek,NCD)
99C125	Alphamerique One(European)	388D105	APC NBK-2104S/C 875644 (EURO) Fcc: GOGAPC-21
103B106	Alpha Micro 106	756D105	APC-21J(X) Fcc:GOGAPC21, Back-L enter
592B106	Alpha Micro Model 62	792D109	APC F21XQ Fcc:GOGAPC-F-21 (also ACE, Softkey)
82B106	Alpha Micro Model 62A(also Ampex)	860D109	APC F-21, W/win keys, Back-L enter, Curve Spacebar (also Nimble)
692B102	Alpha Micro 65 (3 lights)(also Link, Wyse)	909D109	APC F-21YQ (SPK-2000) Fcc:GOGAPC21, Curve Spcbr
966C80	Alphasmart ALF-B01 FCC:K2VALPHASMART001	438E123	APC PC-200055, multimedia, back-L enter (also Perfect Choice)
471D80	Alphasmart 2000/3000 port. Fcc:K2VALPHASMART001	439E125	APC PC-200048, Fcc:GOGAPC-F21, Back L enter, Multimedia (also Perfect Choice)
228E81	Alphasmart 3000 (Euro), Fcc:K2VALPHASMART003	05C108	Apollo/HP A1630-82001
539E90	Alphasmart Dana, Neo #NON-PVT, Rec enter	54C106	Apollo/HP 7121 Rev 1
77C101	Alps SM-101	275A52	Apple II(II(+))
609B101	Alps MPS101 AT101 (also Dell,Samsung)	407A62	Apple II(C)
372C101	Alps MDS101 Fcc:GYIMIDAS101-102	482B65	Apple II(c) Plus
109D101	Alps MCL-101 #10080500 Fcc:GYISAT-101-102 "L" shaped Enter Key	87A63	Apple II(E)
153D101	Alps Metro/AT101 ME39490 FCC:LPZMETRO	785A81	Apple II(E) Enhanced Platinum
231D108	Alps Glidepoint Model MGL , Fcc: CWTCEASC, w/win keys split-spacebar "L" enter key	728A80	Apple II GS M0330
278D109	Alps Glidepoint Model MGM-106 w/win keys, split-spacebar, "L" enter key FCC:CWTCEASC	709C105	Apple Design M2980/2891 "UNIVERSAL" Spacebar Fcc:BCGM2980
560D104	ALPS "WB" SERIES w/Win Fcc:CWTKFRCE	763C106	Apple Design M2980 (European)
		121A76	Apple Lisa
		274A58	Apple Mac M0110
		789B81	Apple Mac Classic/LC M0487
		974B81	Apple Mac Classic/LC (European)

P/N	Description	P/N	Description
645A78	Apple Mac (+)MO110A	236C102	AT&T 305D-LA(also Keytronics)(Euro)
835A81	Apple Mac SE MO116	237C102	AT&T 305B-LA (Euro)FCC:AS593MK305
676B82	Apple Mac SE (European) M0118	802A101	AT&T 304/605 (also Arnet,Keytronics, Samsung,Dell,Rita.US101)
936A105	Apple Mac Extended-Enhanced MO115	271C102	AT&T 304 (102 Keys)EO3417202
696B105	Apple Mac Ext-Enh II (M0312)(M3501)	660B102	AT&T 705
785B106	Apple Mac Ext.II (European)	847B101	AT&T New 705(also Keytronics)
209C63	Apple Powerbook 140/145/170 Port.	508A83	AT&T 6300 (301)
198D77	Apple Powerbook 520C/540C FCC:BCGM4880	553A84	AT&T 6300(+)(302)
505C101A-D	Apple Norsri Adjustable Keyboard (4 pc. set) FCC:DEV-001-0085-01	943A101	AT&T 6310 (303) (also Keytronics, Radio Shack, Phillips)
980C101A-D	Apple Norsri Adjustable (EURO) (4 pc. set) FCC:DEV-001-0085-01	745A103	AT&T 56K 430
677D97	Apple iMac, M2542	777A102	AT&T 56K 470 4425
699D98	Apple iMac (Euro)	700A122	AT&T 6500
66E79	Apple iBook M/N M2453, M6411	707B122	AT&T NEW 6500 (raised f keys)
75E108	Apple iMac, Pro, G4, M7803	528A103	AT&T 7300
108E109	Apple iMac (Euro) Pro, G4, M7803	744A98	AT&T 56K 420
386E79	Apple Powerbook G4, model A1001, Glidepoint	131C102	AT&T 306E(also Keytronics)
563E109	Apple Emac, G5, A1048, 9034LLA, A1046, Bluetooth	153C103	AT&T 306E-FC(also Keytronics)
542E79	Apple iBook M6497 - 11" , Rec enter	272C98	AT&T EO3555001 (also Keytronics)
806A57	Applied Dynamics 57 Switch	416C117	AT&T model OSPS code 56K 114AOP
782A102	Apricot XEN-I(European)	520C138	AT&T Switchboard Keyboard #501013528 Fcc:CIG8AVEQ3417 (also Keytronics)
584B101	ARC KB5181(also Chicony,Hyundai, Magnavox,Headstart,Identity)	526A62	Atari 800
652B101	Arch Rival 386SX(also Hitek,Micronics)	481B84	Atari Mega 1040ST
445C101	Arche SK4100R-1U (also Liteon)	409C95	Atari Mega STE
172E94	Argonaut 900X, Glidepoint, Rec enter, Win.	611B134	Atex (European)
213E94	Argonaut Model#7521, Rec enter, Glidepoint	129B101	Austin 386 KB5161(also Chicony,Samsung)
381E95	Argonaut Model #8575, wins., Glidepoint, Multimedia	768C85	Austin laptop
509E90	Argonaut P14N Laptop, Rec enter, Glidepoint	36C101	Auva KB2101/2102 FCC:HWIA2KB21012 (also Chicony,Handok,Kris Tech,Lead Edge)
510E95	Argonaut 8640, Rec enter, Glidepoint	472C80	Avanti 025 Portable FCC:17NSX025
642E93	Argonaut R15GN/ Ranger 1500M, Glidepoint	342B101	Avar 101 Enhanced
841A102	Arnet Multiuser 102 (also Wyse,Amdek)	35B101	Avtech 200,270 386SX (also Easydata, Everex, Maxiswitch, Gateway,ALR,Opus,Texas Micro)
802A101	Arnet Multiuser 101 (also Keytronics, AT&T,Samsung,Dell,Rita,US101)	938B101	Azuka KB3000/SMK corp
647B81	ASEA MA214/215	749B96	Baublys STG12 (European)
756A138	ASEA DSIH 70 Keyboard	627A74	BBC MicroComputer
297C135	ASEA 47DSIH 80 Keyboard	653D105	Belkin KB6868 Fcc: F8E206 (also Precision)
298B134	ASEA Keyboard BG5735	997D109	Belkin KB6868 Fcc:F8E206, 3 extra keys above directionals (also Precision)
797B101	Aser DFK121/171/191(also Datacomp, Ancer Research,Diamond Flower) Fcc:FBX5E9DFK121	210E107	Belkin KB6868 Fcc:F8E206BLK, back-L enter
41D102	Aser DFK-172/192 (EURO) Fcc:FBX5E9DFK171M	395E108	Belkin F8E208-BLK, ERGO, (KB23-BLK), Fcc: MWIEZ-9000, Back-L enter, Split spacebar
718E136	Aspect Braille keyboard model #3192	455E108	Belkin KB6868 , F8E200, Back-L enter
21B101	AST Enhanced	625E107	Belkin KB-885, F8E885-BLK, Back-L enter
672B101	AST KB101 Taiwan 230082(also T.I.)	727E126	Belkin KB-820, F8E820, Multimedia, back-L enterkey
774B101	AST Enhanced 230098(RT-101+) NMB CMG65001(also Hitek,Versyss)	1236B104	Belkin FE206, 104key, rect enter
478C101	AST Bravo 230402-001A FCC:AQ6ZG-RT687XT KB101 119127-001, Sk1200, Fcc:GYUR15SK (also Hitek,Compaq,NEC,Dec,NCD)	788E104	Belkin F8E206USB - Rect enter key
275C82	AST Laptop 386SX/20 Model 43V	842E108	Belkin F8E223, KB6869, 2 purple keys above directional
254C101	AST SKR1032 (also Radio Shack,Se Jin,Trigem)	903E105	Belkin KB887, Fcc: F8E887-BLK Rec enter
550C82	AST Power/Exec. 3/25i	976B105	Bell & Howell 105ST(also Honeywell)
737C83	AST Bravo NB Laptop w/trackball FCC:HFSLK4	745C105	Bell & Howell P/N 21356 (also Keytronics)
579C101	AST SK-1100 230612-001-A FCC:GYUR10SK (also Liteon,Dell)	746C105	Bell & Howell 5-64995-195 (also Oak)
808C83	AST Ascentia 900A Laptop	790E107	BenQ P010 Fcc IZTIK105M (also Professional)
936C101	AST SK1200 #230851-001C FCC:GYUR15SK (also Liteon, Hitek)	313D48	BigKey FCC: LEWK48-1
957C104	AST RT-6655TW W/Windows Keys (also Liteon, Hitek, Compaq) FCC:AQ6MTN7Z15	57E60	Big Keys LX
170D86	AST Ascentia "J" Series	240B84	Bios XT/AT
171D81	AST Ascentia "P" Series	746B84	Bilink Portable 84 Key
172D82	AST Ascentia 950N	957B101	Bilink Portable PL101
596D89	AST Ascentia "M" Series W/Touchpad, Windows	693C103	Bilink Portable (103 Keys)
124D104	AST 4958TW (also Dec, Hitek)	410C80	BNT Terminal (Behring Nephelometer)
585D104	AST SEM-DC8H FCC:E2XSEM-DC8H (also Samsung)	*****	Boundless Technologies - See ADDS
358E108	AST SEM-DC8L (Euro), Fcc:E2XSEM-DC8L	511B101	Brother TM500 (also Link)
851B101	Astrix 101 (SEE HITEK FOR OTHER MODELS)	843D82	Brother Geobook NB-80C W/glidepoint, Rec enter
542B106	AT 1127	257B84	Brotherbox KS 251
692D101	ATR SK710 Fcc:GYUR12SK (also LiteOn)	442B101	BSC-Blue Star(also Zeos,Nan Tan,NTC,Wang Twin Head,Premier,Dataware,Magtronics)
791B101	AT&T 305/ 305B FCC:A5593MK-305	427B101	BSR-101(also Packard Bell)
		35C101	BSR-386SX FCC:1010DS(also Packard Bell,Leading Tech.Emerson,Cordata, Laser,Samsung,CMS,Se Jin,Leading Edge)
		989A84	BTC 5060 Pyramid Keys
		750A84	BTC 5060 Flat Keys
		811A84	BTC 84 Swith(also Kaypro)

P/N	Description	P/N	Description
54B122	BTC 122 Switch	519A90	Burroughs BETKB-8 NR3388 (European)
72C80	BTC 5100 Mini Kybd- Rec enter	608A95	Burroughs 95 Switch
152C81	BTC 5100 "L" shaped Return Fcc:E5X5R5BTC-5100	815A113	Burroughs T27K3
453E81	BTC 5100C, Fcc:E5X5R5BTC-5100C Rec enter(also Siig)	954B112	Burroughs B-25 K-2 (S.A.)
534B99	BTC 5151	340C114	Burroughs B25-K5
332C101	BTC 5139 BPCS#120019 (also Packard Bell, Reveal) FCC: E5XKBM111 "L" enter key	622B97	Cable Data (also Esprit)
647C102	BTC 5149(Euro)102 Keys (also Packard Bell)	573A72	Cannon TX50
947A102	BTC 5161/5339 Enhanced (also Packard Bell, Hyundai,Minta)	73B101	Cannon Navigator (also Acer,Delta Gold, Nec, Multitech ,Stone, Data General, Texas Instrument)
710C101	BTC 5130 BPCS#120032 FDA1021, SK2100, Fcc:E5XKBM10140, (also Packard Bell)	xxxxxx	CE ALL MODELS UNDER CHICONY ELECTRONICS
884C101	BTC 5169 (rec. Enter) FCC:E5XKBM111	147E90	C.E. M722 Laptop, Rec enter, Glidepoint
529B102	BTC 5339R-O/5349R-O/5339SX Back-L enter (also Pack Bell, Goldstar, Tatung,KLH,Hewitt Rand)	92C101	Celem(Euro)K-108(also Mtek,Monterey)
449C101	BTC 53 Series rectangular Enter Key,no macro Fcc: E5X5RBTC-5339R-O	421B98	Centennial Keyboard
697C102	BTC 53 Series 5339R-O (France-Euro)	120D123	CG Compugraphics #9298-501
962B102	BTC 5339RO (S.A.)(EUROPEAN)	250B83	Cherry G80-0413
184C102	BTC 5349(Euro) (also Pack Bell,Facit, Mitac,Donatec)	176B75	Cherry G80-0414H/07
492C101	BTC 5369 (also Leading Edge)	422B101	Cherry G80-1800,G81-1800 HAU/03 MY1800
116C101	BTC-7000 Series 7339R/7339S	210D101	Cherry MX1800 G80-1838HPU (also Compaq)
698C102	BTC-FT-7000 (Euro)7849R FCC:E5X5R5BTC(also IPC)	873D104	Cherry MY1800,G81-1800 W/Win, Rec enter
649C101	BTC 7XX9/7139 FCC:E5XKBP10110	577E105	Cherry G81-1800LPMES-0/000 (Euro) A7" enter
711C101	BTC 7939 BPCS120029 FCC:E5XKMP10140	560B101	Cherry G-81-3000/ NCR 916 RS3000 G83-3077-SBU
812C102	BTC "BTD-53 Series" FCC:E5X5R5BTC	925D104	Cherry MY3000 Fcc:GDDG81-3000, Rec enter
865C101	BTC 55 Series Fcc: LAKBTC-55 SERIES	856D105	Cherry MY3000 Fcc:GDDG81-3000, W/ Win, "7" enter
07D104	BTC 5539K/55XX w/Windows Keys FCC:LAK55XXK-A1	393B107	Cherry HAD 104 (107 Switch)
08D105	BTC 5131C/SK2100W/BPCS#120059/FDA1051 Win Keys "L" Enter FCC:E5XKBM10510 (also Packard Bell)	395B83	Cherry XT/AT
182D104	BTC 5140 w/windows keys FCC:E5XKBM10410	997B106	Cherry G80-1080 HAU/01
214D105	BTC 5140 w/windows (EURO) FCC:E5XKBM10410	365B102	Cherry 102 Keys G80-1800HAE/07(Euro)
238D105	BTC 5549 w/win keys(Euro) FCC:LAK55XX-K-A-1	448B102	Cherry Pyramid G80-3012HAD (European)
428D104	BTC 5530K w/win keys FCC:LAK55XXX-A2	714B102	Cherry G80-1251-SAD (European)(Tandon)
321D105	BTC 5530K-SP (Euro)w/win keys FCC:LAK55XXX-A2	490B101	Cherry G81-1000H/G81/G81-1600 SAU
464D110	BTC 8110 Fcc:E5XKBP10920U W/Win	536B101	Cherry G81-3000-HAU/03 (European)
183D108	BTC 8120 ERGO 2 part keyboard w/windows Fcc:E5XKBP10910U	537B102	Cherry G81-3000-HAB/04 (European)
375D104	BTC 7931 FCC: E5XKBP10410U	557C101	Cherry G81-1900 HDU/17 C/C Reader
356D104	BTC 5121 FCC: E5XKBM104M10UC w/win "L"enter	309C101	Cherry G81-3100 SDU/03 C/C Reader
140E104	BTC 5121 FCC: E5XKBM104M10UC w/win Rec enter (also Micron)	540B102	Cherry G80-1000-HAD/16 (European)
361D105	BTC 5121 (Euro) E5XKBM104M10UC w/win keys	387C105	Cherry G80-1191-HBU(also Tandem)
752D107	BTC 5121W Fcc:E5XKB5121WTH0110 Back-L enter Three extra keys above Directional keys	738B107	Cherry G80-1114-HAO (also CTM) (European)
851D108	BTC 5121W (Euro) Fcc:E5XKB5121WTH0110, Win, "7"enter	61C126	Cherry G80-2507HAD(also Siemens-Nixdorf, SINIX (European)
922D108	BTC 5201 (Euro) "7" enter	200C106	Cherry/Tandon G80-1207-HAD/04(Euro)
809D86	BTC 5510M Mini keyboard, Rec enter, Windows	267C123	Cherry G80-2100 Hau/02
56E107	BTC 5123S/5201 Fcc:E5XKB5121WTH0110, Back-L	338C105	Cherry G80-3314-HAU(also Triad)
237E107	BTC KB5201 Fcc: E5XKB5121WTH0110 back L enter	528C103	Cherry G80-1600 HAU/17
74E120	BTC 9000, Fcc:E5XKB9000TH0010, Multimedia	667C83	Cherry ML4100 FCC:GDDG84-4100
105E109	BTC KB5301 (Euro), Fcc:E5XKB5301, "7" enter	690C101	Cherry MY1600 G81-1600SAU
236E107	BTC KB5199, KB5197, Fcc:E5XKB5199, back-L enter	190D101	Cherry MY3100 Credit Card reader
312E109	BTC KB5199 (Euro), Fcc: E5XKB5199, A7" enter	811C117	Cherry G80-3190HPU w/ cc reader
258E107	BTC KB5126T Fcc: E5XKB5126TH0610, rec enter (Also Tagent)	982C86	Cherry ML4400 w/trackball G84-4400-RAU
505E104	BTC 7932M, Rec enter (also Wyse)	45D21	Cherry MX3700 Keypad G80-3700-HAU
516E107	BTC 5107 Fcc:E5XKB5301, P/N 5187-1734 Back-L enter, (also HP)	130D101	Cherry RS6000 G83-6000-LPAUS, PCXAC-GA #598-0011730
1672B107	BTC 5201 (also HP)	188D102	Cherry RS6000 (EURO)FCC:GDDG83-6000-LABG
1801B104	BTC 7800	123D104	Cherry RS6000 w/ win G83-6104LAMUS101
90C100	Bull Questar 210(European)	123D104-Revised	Cherry RS6700
658B105	Bull Questar 400 (European)	189D105	Cherry RS6000 w/windows(EURO)G83-6105
455C115	Bull Questar KBU3103(Euro)	458D105	Cherry G83-6105LC(Euro) Fcc:GDDG83-6000
737B107	Bull (Honeywell) BDS-3	470D104	Cherry MY7000 G81-7000LABUS/03
967B93	Bull BDS-1/M9048	515D86	Cherry ML4100 w/win keys
03C107	Bull M22(also Honeywell,Memorex)	504D104	Cherry RS8000,MY8000, G81-8000LPC-US, G81-8008L W/ CreditCard Reader, Win Keys
523A98	Burroughs B25/B26/B38	701D130	Cherry MY8000 G81-8308LPAUS
519A90	Burroughs Et 1100/2100	597D104	Cherry MX11800 G80-11801LPAUS, Fcc:GDDG80-11801
		639D120	Cherry MX8000/G80-8200
		799D122	Cherry MX8100, G80-8113LRAUS/02, w/ c/c reader, Win Keys, Glidepoint
		663D112	Cherry G80-3181HPU POS
		673D106	Cherry G80-11900 W/Touchpad
		674D13	Cherry POS MX1950 (Universal)
		265E117	Cherry MX3160, G80-3180HQMUS/00 Win. Keys, glidepoint A7" enter
		306E107	Cherry MX11900, Fcc:G80-11900LPMFR/07 A7" enter
		159B84	Chicony 5160 AT/XT

P/N	Description	P/N	Description
129B101	Chicony Enh 101/5161(also Austin,Samsung) Fcc:E8H5IKKB-5161	183B101	C.Itoh Enhanced 101
476B102	Chicony KKB5162 (European)	311B108	C.Itoh 223/224/324/326/328/334
584B101	Chicony 5181(also Hyundai,Magnavox, Headstart, ARC,Identity)	587B108	C.Itoh 344
669C102	Chicony 5182 FCC:E8H51KKB-5182(also Mitac)	245B102	Citizen Mate 12
219B101	Chicony 5191(4 raised lights)	35C101	CMS 386SX/16(also Leading Technology, Cordata,Laser Samsung,Se Jin,Packard Bell, Emerson,Datatrain, Leading Edge)
36C101	Chicony KB5191(also Leading Edge Handok,Kris Tech,Auva)	592D88	Coded Communications MLT-2000 Fcc:FKGD75
682B102	Chicony Magix 5192 (European)	540A83	Columbia P.C.
723C102	Chicony 102 (EURO-UK)	862A120	Comex 120 Switch
217C85	Chicony/ULTRA 386SX-20mhz(also Epson)	76A66	Commodore Vic 20/64
246C101	Chicony KB-101 (Euro)	09B66	Commodore 64C
424C101	Chicony KB-5311 FCC:E8HKB5311 (also CompuDyne,Addison)	842A92	Commodore 128
721C102	Chicony KB5312 (EURO) FCC:E8HKB5311 (also Kodak)	843A89	Commodore Amiga 1000
243C101	Chicony KB-5391	137B94	Commodore Amiga 500/2000 KKQ-E94YC
397C101	Chicony KB5581A with Trackball Fcc: E8HKB-5581A (also PC Accessories)	404B85	Commodore PC 5
720C92	Chicony KB-5591 with Trackball Fcc:E8HKB-5591 (also Addison)	403B101	Commodore PC 10 Series III
273C101	Chicony 100M/OK-100M FCC:IZEOTCOK100M	509B102	Commodore PC 10F (European) ***** Compaqs are also listed under Hewlett Packard
761C101	Chicony KB5331 FCC:E8HKB-5311 (also Ultra)	489A83	Compaq 286 Portable/Portable(+)
782C101	Chicony KB8851 FCC:KM988KKB8851	652A84	Compaq 286 Deskpro(L-Shaped Return Key)
776C102	Chicony KB-7001 Ergo Kybrd FCC:LIAKB7000 (also PC Concepts,Ace,Addison)	731B80	Compaq LTE 286 Portable
108D104	Chicony KB5911 w/windows keys E8HKB-5911	888A84	Compaq Portable II
496D105	Chicony KB5911 W/Win (euro) Fcc:E8HKB5911	36B84	Compaq Portable III
916C104	Chicony KB5923, KB6923 FCC:E8HKB-5323 w/win keys (also Reveal,SIIG,IBM)	428B91	Compaq 386 Portable
132D105	Chicony KB5923 (Euro) Fcc:E8HKB-5323	867A101	Compaq 386/286 Enh FCC:CNT8AV106288
986C101	Chicony KB5323/KB6323 FCC:E8HKB-5323 (also Zenith,IBM)	238B101	Compaq 386-20E Enhance II /386S Fcc:CIGEO35074, AQ6ZG-CCC, 140536-101 CNT47K109232
888C101	Chicony KB2313 FCC: E8HKB-2313	475B102	Compaq 386-20E/286E/386S (European)
998C104	Chicony "ERGONOMIC" w/windows keys KB7903 (also Fellowes)	535B82	Compaq 2680KB/SLT 286 Portable
931C104	Chicony SKR-2033	577B83	Compaq SLT/286 (European)Portable
151D102	Chicony KB5323 (EURO)(also Zenith,IBM)	583B92	Compaq 386 Portable (European)
248D104	Chicony KB7923 FCC:E8HKB5923 (also Sony)	247C101	Compaq Prolinea RT-6271T, 141648-101 Fcc: AQ6MEMB74004 (also Hitek)
160D104	Chicony KB8923 FCC:E8HKB5923 (also IBM)	290C102	Compaq RT-102 (Euro-S.A.)(also Hitek) Fcc:AQ6MEMB-74004
220D105	Chicony 8926 w/win keys (Euro) Fcc:E8HKB5923(also IBM)	478C101	Compaq RT-101(+)FCC:AQ6ZG-RT-687XT 119459-001 160650, AQ6MTN4XZ15 (also Hitek,AST,NEC,Dec,NCD,Addis)
132D105	Chicony PCK104-SKB (EURO)FCC:E8HKB5323 (also Unisys)	208D102	Compaq RT-102 AQ6-CYPRESSC15 (EURO) (also Hitek)
201D104	Chicony KB2923 FCC:LIAKWD-200 (also Mousesystems)	596C79	Compaq Contura Model 2820 Laptop Fcc:CNT75MBZ4
793D104	Chicony European Fcc:LIALWD-200	622C101	Compaq KPQ-E99AC "Rectangular Enter Key" FCC:EW4KPQ2479A 160648-101 (also Mitsumi,Hitek)
325D104	Chicony KB5981 w/win keys FCC:E8HKB5981	642C79	Compaq LTE Lite Series 2810 FCC:CNT75MAFA
320D104	Chicony KB2931 w/win FCC:E8HKB5923	918C101	Compaq Vocalyst FCC: CIGEO3783
532D104	Chicony KB2961 fcc:E8HKB-2961, Back L enter	919C79	Compaq Concerto Notebook
899E105	Chicony KB2961 Back L enter Single back space key	913C101	Compaq P/N 120663-001A (also Hitek) Fcc: AQ6-CYPRESSC15 rect. Enter key
808E104	Chicony KB2961 - Rect enter (also Gateway)	55D82	Compaq LTE Elite 4/50E Series 2850D Fcc:CNT75MB1CD Portable
538D104	Chicony PCK104-SKB FCC: CMYKPKQ7615/ Fcc: KPQE99ZC-13 (rect. Enter)	79D76	Compaq Contura Aero 4/33C Series 2830A Fcc:CNT-75MBZEA Potable
721D118	Chicony KB9805 Multimedia (also Toshiba)	176C85	Compaq Contura 430C series 2860 w/trackball Fcc: CNT75MB2CC
723D105	Chicony KB3963 w/win, rec enter, ez button	210D101	Compaq/Cherry MX1800 G80-1838HPU
03E107	Chicony KB-9850, rec enter	230D105	Compaq RT7A56TW 237743-301 w/window keys rectangular enter FCC:AQ6-MTN41Z15DIP KPQE99ZC-13 Split spacebar
112E104	Chicony KB2971, Back L enter (also eMachines,Fellowes)	253D106	Compaq RT7A56TW (EURO) w/window keys Fcc:AQ6-MTN41Z15DIP split-spacebar
794D04	Chicony KB2971, Rect. enter (also eMachines)	228D105	Compaq RT-685BTW 121838-001A w/win,rect enter,FCC:AQ6-CYPRESSC15,split spacebar
152E121	Chicony KB-9885, Rec enter, Multimedia (also Systemax)	276D107	Compaq RT-685BTW (EURO) split-spacebar Fcc: AQ6CYPRESSC15
958D110	Chicony KB-9908 (also emachines)	250D104	Compaq RT6L5CTW w/page scanner,win keys 121307-001 FCC:AQ6-LONGBAYZ15
669E104	Chicony KB-8861XPL, Fcc: KM988KKB8861, Back-L Enter, Numeric pad left side.	957C104	Compaq RT-6656TW/6655TW,RT6600TW,235212-101 (also Hitek,AST,Liteon)
665C125	Chyron Maxine KB PESA1124	326D104	Compaq RT-2156/RT-2257TW w/win keys(also Hitek) Fcc:AQ6MTN71BZ15DIP/ Fcc:AQ6-71Z15/AQ623K15
740C119	Chyron Super Scribe KB		
48D108	Cirque GKB330/340 with glidepoint Fcc:GYUR33SK (Also Reveal, Liteon ,PC Concepts)		
395D04	Cirque Glidpoint Touchpad2 model GDB400 Fcc:1GSCC0003		
415D108	Cirque CIC360 FCC:L2BACEKEY220 W/Windows and Glidepoint "L"enter (also Acekey)		

P/N	Description	P/N	Description
322D105	Compaq RT-2257TWLA (Euro) w/win keys Fcc:AQ6MTN71BZ15DIP	570E91	Compaq NX7000 Laptop Glidepoint, Rec enter w/Win
394D85	Compaq 5300 Laptop w/trackpoint #213519 LTE 5280	638E104	Compaq SK2875,SK2885, KB0316, sml4000, 9109 rec enter (also H.P.)
79E101	Compaq RT235BT, Fcc:AQ623K15, Rec Enter	652E96	Compaq NC4000 Laptop Series PP2170
417D105	Compaq RT231BTW,247430-001 w/win keys Split space bar Fcc:AQ6-72BC15	690E93	Compaq NC6000 Laptop
426D104	Compaq RT231BTW full spacebar AQ6-72BC15 KB9860, 166516-001	2023B104	Compaq 5185, KB-0311, 5187-5023, RT7H00
80E105	Compaq KB9860,166516-001 (Euro) "7" Enter	693E115	Compaq model 5185, 5187-5025 (Euro) A7" enter
463D104	Compaq RT5158TW Fcc:AQ6-8Z15 W/Win	705E90	Compaq NX5000 Laptop with Glidepoint (also HP)
489D87	Compaq Armada 1540/1550DMT Series2920A Fcc: DGIP5665	714E107	Compaq 5107 Fcc: E5XKB5301, 3 buttons top of Numeric keys, rec enter
518D88	Compaq Armada 4131T Laptop W/touchpad	715E108	Compaq 5107 (Euro), Fcc:E5XKB5301 A7" enter
597D104	Compaq MX11800, G80-11801LPAUS Fcc:GDDG80-11800	771E104	Compaq SK-1788 (also Sejin)
160D104	Compaq KB3923 fcc:E8HKB5923 (also IBM, Chicony)	778E84	Compaq Tablet PC Series PP3000
631D117	Compaq Presario SK2700 fcc: GYUR55SK	826E121	Compaq RT7H10 (also HP)
632D118	Compaq Presario SK2700 (Euro) Fcc:GYUR55SK	830E93	Compaq NX9005, NX9030 laptop (also HP)
641D104	Compaq ConcertMaster RT915CTW	855E92	Compaq NC6120 laptop
661D93	Compaq Armada 7330T/7380MT Laptop	874E108	Compaq 5137 , 5188-0989, Fcc:E5XKB5137
676D90	Compaq Armada 7700DMT Portable	566C101	Compuadd 2192004(also Maxiswitch)
776D98	Compaq Presario #1260 Laptop Fcc:CNTTAI-24639 W/Win Keys, Touchpad, Speakers	586B101	CompuAdd 286 (also Mitsumi) KPQ-E99YC
889D122	Compaq SK2800 Fcc:GYUR66SK, GYUR79SK, Mltmda	231C101	CompuAdd 55153 RT-101(+)(also Hitek)
857D123	Compaq SK2800 (Euro),Fcc:GYUR66SK W/win, Multimedia	437C86	CompuAdd Express 325 NXL Laptop w/trackball model NB25SXL FCC: IYL1398995
928D95	Compaq Prosigna 150 M/N1456VQLIN, Fcc:H8NTAI-27108-M5E, rec enter, glidepoint	545C84	Compudyne Slimnote Portable CMPD3 SLX/25 Fcc: FKGLIMNOTE-SX
933D90	Compaq Armada 1750, Fcc: CNTTAI-32808-M5E, Glidepoint	424C101	Compudyne KB-5311 FCC:E8HKB5311 (also Chicony,Addison)
934D93	Compaq Armada 3500, trackpoint, Win. keys	80D104	Compuphone 2000 FCC:LVNEY5754-K616
960D88	Compaq Armada V300, M/N 1456VQLIOJ, Fcc:H8NTAI-27397-M5E, rec enter, glidepoint	722D122	ComputerLab 122 key
171E91	Compaq Armada M300, Glidepoint, "7" enter	917D101	ComputerLab 101 Key
23E104	Compaq KB9965,w/win, 269513-001, 166516-006	287E122	ComputerLab BTUS012725655 A7" enter
988D105	Compaq KB9965 (Euro) w/win keys	443D104	Compucessory 30210 Fcc:F2QKT95104 (also Qtronix)
373E101	Compaq KB9965 us version, Philips#M3180-40010	291B101	Computrend SK-8801(also Liteon,Jade,KLH)
374E102	Compaq KB9965 French version Philips#M3180-40011	400B44	Comterm Portable
375E106	Compaq KB9965 Japanese version Philips#M3180-40012	254B84	Contel 84 Switch/C321
24E111	Compaq SK2855,SK2850,SK1800, GYUR70SK, GYUR85SK, Multimedia, rec enter	509A87	Control Data 87 Switch 722-30
64E112	Compaq SK2855, (Euro), "7" enter Multimedia	937B101	Copam K450 FCC:DXO6SCK-450
60E90	Compaq Armada 100, Fcc:H8NTAI-40049-M5-E	547C101	Copam K455 FCC:DXOKB453P
73E122	Compaq SDM4540UL, KU9978, P/N 179355-007, Kus0060, Multimedia	18B84	Cordata CS 40
72E123	Compaq SDM4540UL (Euro) P/N 179355-1667 Multimedia	35C101	Cordata 286/386 FCC: 1010DS (also Packard Bell,BSR,CMS,Leading Tech,Laser, Samsung,Emerson,Se Jin,Leading Edge)
84E93	Compaq Armada 7800 Fcc:CNTSNG-32811-PT-E	571B101	Cosmo Keyboard FCC:GXD3PNLB101A
94E109	Compaq SK-1689,(Euro) Fcc: GYUR89SK "7" enter, (also Dell, Liteon,AIMC)	149E88	CPI #861, Wireless Keyboard, Rec Enter
96E112	Compaq SK2860, KB9963, KB9965, SK2865, Fcc:GYUR86SK, Multimedia, Rec Enter	999D108	Cramer KB-10, Fcc:L2PWPD1BBC, Rec Enter
118E113	Compaq SK2860, KB9963 (Euro) Fcc: GYUR86SK Multimedia, "7" enter	941B101	CSK-7101/1101 (also Recortec) FCC:GS23TYCSK1101P
238E104	Compaq SK-1688, Fcc:GYUR84SK, Rec enter, Windows	322C102	CSK-7102S/1102S(Euro)FCC:GS23TYCSK1101S
376E105	Compaq Sk-1688 (Euro), Fcc:GYUR84SK, A7" enter	817B101	CSR 286/128 SL (also Focus,Proteus)
308E98	Compaq EVO N160,EVO 2150, 900Z, Model #Capra, 1456VQLIT, Fcc:H8NTAI-36177-M5-E	34C101	CSS 101 Fcc: 1010R2 (also Leading Technologies,Samsung,Se Jin)
379E95	Compaq EVO N600C, M/N JO7M04000, Fcc: 6CTTAI-35763-M5-E	251E116	CTL 5800, Multimedia, back-L enter
361E95	Compaq Armada 110 Laptop, Glidepoint	738B107	CTM KS90 (European)(also Cherry)
365E06	Compaq Pocket PC	883B111	Cumulus 466
396E112	Compaq KB-0133, KU3923, 4700P Rec enter, multimedia	851B101	Cumulus GLC 386SX (SEE HITEK FOR OTHER MODELS)
372E113	Compaq KB-0133 (Euro), A7" enter, Multimedia	233C102	Cumulus 386SX(also HQK,Identity)
459E90	Compaq EVO N1000C Series PP2140, Trackpoint& Glidepoint	908C93	C & W 93 Key
548E109	Compaq KB-9968 Trackball, Rec enter	909C84	C & W 84 Key
607E00	Compaq EVO N180 Laptop	509C101	Cybernet 101 (also AIC)
605E88	Compaq EVO N1000V, N1015, N1020	662D104	Cybernet Keyboard PC Station (also AIC)
606E85	Compaq Armada M700	936D108	Cybernet "Elite" zero footprint, Multimedia
560E100	Compaq N800C Laptop Rec enter, Trackpoint, Glidepoint	229E105	Cybernet Elite II Zero footprint PC
		786E111	Cybernet ZPC-9000
		*****	Dah Yang ALL MODELS SEE UNITEK/UNIT TECH
		945B108	DAS AT1183
		438B101	Dasher 386SX (also Data General, Emerson,Fujitsu,Earthstation, Sanyo,Vendex,Tatung)
		120A90	Dasher SN7 (also Data Gen.)
		519D81	Data911 (also MDS)
		709B91	Datacard (Euroean-France)
		797B101	Datacomp DFX121/171m/191(also Aser,Anser, Diamond Flower) FCC: FBX5E9DFK121
		430B101	DataDesk 101
		326C105	DataDesk Mac101E model1069 FCC:E98-1069

P/N	Description	P/N	Description
26C111	DataDesk Turbocalc III (also Focus)	800D115	Dec MTXLA-BA W/ Credit Card Reader
232E83	DataDesk Little Fingers LF2000, Trackball, Back-L enter	70D83	Dec Portable HINOTE Ultra 433 w/trackball FCC:A09-D7XNOTE
438B101	Data General GG488A (also Dasher,Sanyo, Vendex, Fujitsu ,Earthstation, Emerson, Tantung)	124D104	Dec RT4958TW (US) FCC:AQ6MTN7Z15 w/windows keys (rect.enter key)(also Hitek, AST)
120A90	Data General D-2 (also Dasher)	91D105	Dec RT4958TWLA w/windows keys (EUROPEAN) FCC:AQ6MTN7Z15 121166-013
119A101	Data General D100/200	186D101	Dec PCXAL-GA FCC:CIGEO36004(also Keytronics)
205A107	Data General 210/215/220/410/460/470/6246/6346	414D92	Dec Laptop PCP34 w/trball FCC:DJKPWRE48625SL
12B107	Data General 214/6348 21"	572D88	Dec HiNote VP575 laptop TS30G fcc:II RTS31GZ
276B107	Data General 6348 Rev 01-A 19" N860-4735	916C104	Dec KB5923 Fcc:E8HKB5923 (also IBM, Chicony)
532B79	Data General Walkabout G2750/85 pt#119-1900	715D89	Dec HINOTE VP TS30H Laptop
901B86	Data General Walkabout SX Portable G2762A	555B83	Decision Data 3496(83 key)
758B106	Data General Model 18902 (119-2125)5220MT (also Keytronics)	849A103	Decision Data Enhanced 3496
645B102	Data General 6312-K (Euro) (also Acer)	384B103	Decision Data 3596-01 (103 Switch)
73B101	Data General 6311-K (also Acer,NEC,Multitech, Cannon,Stone Systems,Delta Gold, Tex Instr)	415B122	Decision Data 3596 (122 Switch)(also HP)
317C101	Data General 5222MKYB/EO3624E (also Keytronics)	71B124	Decision Data 3781
963B100	Datalux TIRUC	190B83	Decision Data 3761(83 Switch) (full size keys)
304D100	Datalux CIRU-30/40	588B83	Decision Data 3761(83 Switch) (Pyramid Keys)
246D94	Datalux model MOGUC w/glidepoint	305C122	Decision Data 122RX-31S-1E(also Honeywell)
283D94	Datalux TIGUC	344C102	Decision Data 102 Model 3777/3778 FCC:102RX31S-1E (also Honeywell)
364E93	Datalux MOGUW, glidepoint, rec enter	609B101	Dell 101 (also Alps,Samsung)(No Pencil Bar) AT101R/AT103R GYUM97SK/GY13PVAT101
423E93	Datalux TOGUC, Rec enter, Glidepoint	192B101	Dell Enhanced 101
728E100	Datalux keyboard	802A101	Dell 310/325(also Keytronics, AT&T, Samsung,Arnet,Rita,US101)
661B107	Datamaxx Ext. 4300	14C101	Dell 101WN(also HONEYWELL,Dec)
750B103	Datamaxx 1200	628A101	Dell 1397651 (also IBM,Lexmark)
338B101	Datamaxx 1227 (also Keytronics,AGI, Mitubishi,Goldstar,Premier,Spear Technology,Gateway)	251C85	Dell 325N Laptop Portable
770B107	Datamaxx 7310(+)	483C85	Dell NL25 Portable FCC:DG1D3216
875B111	Datapoint 94-7393XX (European)	579C101	Dell SK1000RS FCC:GYUR10SK "Rect Enter Key" (also Liteon,AST)
876B76	Datapoint 94-5330-002 (European)	221D102	Dell SK1000RE (Euro)FCC:GYUR10SK
934C109	Datapoint 94-7391-101	725C102	Dell 102 (EURO-UK)
128B122	Datastream 122 Switch	648C102	Dell AT102 (Euro) FCC:GYUM97SK (also Sysmex)
597B84	Datavue Snap 1 + 1 Portable	914C84	Dell Latitude LX4100, Fcc: HFSBLX DELL #07427
891A77	Datavue Spark Portable	209D87	Dell Latitude Laptop XPI-P75D w/trkball
442B101	Dataware KB6251/EM(also Zeos,NTC,Wang, NanTan,BSC,Twinhead,Premier,Magitronics)	430D89	Dell Latitude Laptop LM TS30G w/glidepoint FCC:11RTS30GS w/windows keys
35C101	Datatrain 101 GJJ4AKEAT-1010DS(also CMS, Leading Tech,Cordata,Laser,Leading Edge, Samsung,BSR,Emerson,Se Jin,Packard Bell)	576D88	Dell Latitude PPS, XPI CDP150ST
798B101	Datatrain 989-002(also Maxar)	542D90	Dell Inspiron 3000 model#TS30H #32304 Laptop w/Window Keys and Glidepoint
426C101	Datatrain SEM-K20N-1 (also Samsung) Fcc:E2XSEM-K20N	09D104	Dell "Quietkey" SK1000REW/SK2000REW/RT7D5JTW SK8000, Fcc:GYUR26SK/GYUR43Sk (also Liteon)
346B84	Daytronic 84 Switch	221D102	Dell SK1000RE (Euro)
989A84	Daytronic IPC	137D101	Dell Model SK-MDK w/speakers GYUR13SK
66A83	Dec VT 100/101/102/103/131	146D104	Dell AT101W w/windows keys FCC:GYUM92SK, GYUM905SK
148A18	Dec VT 100-18 Button Aux.Station (\$3.50 Ea.)	327D105	Dell AT102W w/win keys(Euro)FCC:GYUM92SK
109A69	Dec Writer II LA36	340D105	Dell SK1000REW(Euro)GYUR26SK w/win
599A83	Dec Writer III LA120	669D90	Dell Latitude CPI, PPL, CPM233XT
295A105	Dec VT 220/240/Rainbow/ Dec Mate II/III(+)	965D93	Dell Latitude Model PPX, PCX-J, Fcc: CPTV466GT, Rec enter, glidepoint, win. keys
295A105	Dec LK201AA / Dec 320	956D91	Dell Inspiron 7500 M/N PPL, touchpad
157B105	Dec LK 207EE/330/340	94E109	Dell SK1689, Fcc:GYUR89SK, (Euro), "7" enter (also Compaq, AIMC, LiteOn)
151C101	Dec LK 443AA/LK441(also Honeywell,Memorex,Telex)	146E94	Dell Latitude C500, C510, C600, C610, 4100, 4150 PPO1L, Rec enter, Glidepoint
354C101	Dec PCXAL-AA cat#101WN63S-8E FCC:GJK101RX-6 PC7XL-AA (also Honeywell,Tektronix)	177E108	Dell RT7D00, SK8100, SK8110, RT7D20, 07N242 Fcc:7D080C0B, win. Rec enter
355C101	Dec PCXAL-AA cat#101RX435-71 FCC:GJK101RX-4 (also Honeywell)	231E109	Dell RT7D00 (Euro), A7" enter, windows
767B108	Dec VT-420 LK401AA/LK411AA LK-450,VT-520 598- 001-2208, 297-9003-9000 598-0013684 (also Adds)	863E109	Dell SK8110- Japanese
89B101	Dec 433 PC(EO3443)(also keytronics,Unisys)	45E81	Dell Inspiron 5000E (also Systemax)
274C84	Dec PC320P Notebook Portable FCC:ACJ9TG25-3572	240E88	Dell Latitude L400, model #PP01S, Fcc:LNQUSA-34266-M5-E
519C74	Dec LK-421AA Cat# 74RX33S-3E (also Honeywell) FCC: A09LK421	343E91	Dell Latitude C400, PP03L, fcc:5ZXMUL-36273-FBE
14C101	Dec PC7XLAA "L" Shaped Enter Key FCC:GJK101RX-6(also Honeywell,Dell)	259E94	Dell Latitude C800, PP01X,
620C24	Dec LK901 Keypad FCC:2ELK901-AB	446E94	Dell Latitude C840, PP01X, glidepoint, Rec enter
478C101	Dec 101 RT-101+ (also Adds,Hitek,NCd,Compaq,Nec,AST)	976D107	Dell KWD-820 (also PC Concepts)
670C102	Dec RT-102(EURO) 119691-013 FCC:AQ6ZG-RT687XT(also Hitek)	284E112	Dell RT7D10, Fcc:AQ6-7D10 (7 buttons across top)
664C86	Dec 325P PCP12 Portable FCC:ACJ9TG25-3573	891D116	Dell itouch 86719-0403, YRB-6 (also Logitech)
332B101	Dec-200 (also Radio Shack,Panasonic)	472E118	Dell RT7D30, RT7D40, Fcc:AQ6-7D30, Rec, Multimedia
843C85	Dec Hinote 433 w/ trackball	567E119	Dell RT7D30, RT7D40 (Euro) A7" enter
912C121	Dec MTXLA-BA P.O.S. Computer	537E105	Dell RT7D20 (Euro) A7" enter

P/N	Description	P/N	Description
587E111	Dell Sk8125 Multimedia, Rec enter	35C101	Emerson 8300SX FCC: 1010DS (also Packard Bell,BSR,CMS,Samsung,Leading Tech, Laser,Cordata,Se Jin,Leading Edge)
592E93	Dell Latitude D500, D600, PP05L, Rec enter, Glidepoint, Trackpoint. Keys Covered ONLY	541B102	EMAG-COMM 102 Model 88101C (European)
897E90	Dell D510 laptop PP17L, P/N U8327A02, Fcc E2k24Bnhm	305D88	EPS Technologies Laptop model ARa FCC:EHARA
1800B87	Dell Inspiron 2500, 8100, 8200 Laptop	103A70	Epson Hx-20
1887B85	Dell Inspiron 2600, 2650, PP04L	498A72	Epson Hx-40
1887B85	Dell Inspiron 5100, 1100,1150, PP07L	541A67	Epson Px-8 Geneva
604E87	Dell D800 Laptop (not available as of 4/1/05)	766A83	Epson Equity I/II/III(83 Keys)
673E101	Dell SK3210, rec enter, Trackball	123B01	Epson EHT-10
716E90	Dell D505 laptop model PP10L	911A101	Epson Equity I+/II+/III+/ENH Q203A 101 Keys
726E104	Dell SK-8115, RT7D50	412B72	Epson PX-4
784E105	Dell SK-8115(Euro)	563B23	Epson PX-16
1925B104	Dell SK-3106 with credit card reader	514B102	Epson Equity III(European)
856E104	Dell RT7D60 with Credit Card reader	745B101	Epson 386XT(Fujitsu TO26A)
845E119	Dell SK8135	73C84	Epson NB3s Portable(European)
884E120	Dell SK-8135 (Euro)	74C84	Epson L2 Portable(European)
1874B087	Dell Inspiron 4000 Laptop	98C102	Epson A800221/800210/KB03-WG (European)
847E88	Dell Inspiron 1200, 110L Laptop	195C84	Epson NB/SL Port.(Euro)(also Fujitsu)
81C127	Delta Data 8303 (European)	217C85	Epson Port.386(also Chicony /Ultra)
73B101	Delta Gold (also Acer, Stone, System,Cannon, NEC, Multitech, Texas Instrument,Data General)	450C101	Epson Equity IV N860-4871-T001(also Fujitsu)
695E119	Designer KB-558, Multimedia, Back-L enter	542C82	Epson Action 486 Notebook(also Mitsumi)
841E101	Desko Keyboard made in Germany	968C88	Epson Action Notebook 650C w/trackball Fcc:11RTS38MS Model TS30AS
865E106	Desko Keyboard made in Germany	478C101	Epson RT101 AQ6MTN56Z15 120559-001
797B101	Diamond Flower KB-101-E(also Datacomp, Aser, Anser)	455D105	Epson FKB8720 (EURO) Fcc: C9SKB8720
727B101	Digicom K-160/K-260 (also Unit Tech,Minta)	544C114	Ericcson Keyboard (S.A.)
460B68	Digicom MDT-870	921A85	Esprit 6110(+)
530C85	Digicom (also Electrocom) MDC890	274B109	Esprit 3NL/Opus 2/400(T5503)
504A51	Digicom (also Electrocom) MDT 800	567B108	Esprit 108 key
477D104	Digiponto EPD-FP100 86-2101/21	622B97	Esprit 6310 (also Cable Data)
483D104	Digiponto EPD-FP100 Fcc:KUG-SGC200 W/Win	248C97	Esprit 6310N(New full keys)
484D107	Digiponto SG-C200 Fcc:KUG-SG-C200 (EURO) W/Win	102C108	Esprit 6515
*****	Digital (all Models) SEE DEC	219C103	Esprit 200 PC Enh.(T5502)
685D104	Digital Research DRKey104	278C102	Esprit PC E400 PCE
759D124	Digital Research DRKEY124 Fcc: F2Q4NE98 (also Qtronix)	538C101	Esprit 400/200-PCE (T5513)119489-001 Fcc:AQ6ZRT687XT, Back-L enter (also Hitek)
760B105	Digitran KD0220	560D104	Esprit "WB" SERIES W/WIN FCC:CWTKFRCE
122B108	Ditto 320 XL	100D104	Esprit T404C, T405C, (Also Keytronics)
184C102	Donatec 102 (Euro)(also BTC,Facit, Packard Bell,Mitac)	373C105	ETC Peripherals Power Glide 105 FCC:GMB3ZT-MAK-105(also Power Glide)
717A50	Dreamer Keyboard	917C86	Eurocom 8200 Notebook
890B102	DTK SPK-101	35B101	Everex Step 20PC (also Maxiswitch, Texas Micro, ALR,Gateway,Opus,EasyData,Avtech)
163C102	DTK-SPK-102C	851B101	Everex 116920-001/118235-001 (SEE HITEK FOR OTHER MODELS)
40D101	DTK SPK-105E FCC:GOGAPC-21(also APC)	38C82	Everex Tempo LX 386SX/20 (Also Zeos)
851B101	DTK Grafica MBK-1013 RT-101+(also Hitek) Fcc: AQ6RT101-LC(SPK-103)119411-001	575D88	Everex Stepnote Plus3500 Series Laptop Fcc: E3EEX-2AOOV-XYDP
327C102	DTK model MBK1013A FCC:F825K4SPK-102	607D90	Everex Stepnote SE Port. W/Win keys & Touchpad
477C101	DTK KB-101N 119976-01(also Hitek,ALR)	620D88	Everex Stepnote MX W/Touchpad Fcc:EUNDIGNOTE6
215C101	DTK EO3601ELDTK M/O 44563460 FCC:CIGEO36004 (also Keytronics)	109C102	ExpoTech 8110205 (also Laser)FCC: IFS80-2269-1
784C122	Dupont D2911B	208E91	EZZTouch Notebook #34052, Rec, Glidepoint
477C101	Duracom 120340-002 FCC:AQ6CYPRESSZ15 (Hitek)	209E93	EZZTouch Notebook #2700C, Rec enter, Glidepoint
920E123	Dynex DX-MKB101	948A108	Falco 522OE
935E109	Dynex KB-118	152B106	Falco Enhanced AT/ ASCII
35B101	Easy Data Model 216 (also Maxiswitch,ALR, Avtech,Gateway,Everex,Opus,Texas Micro)	266C108	Falco 5220 Pyramid Keys(old Style)
438B101	Earthstation I/II FKB-4700(also Sanyo,Vendex Emerson,Fujitsu,Data Gen,Dasher,Tatung)	786B99	Fame II
994A101	Earthstation I/II(also Wells American,Hitek)	258C101	Fame TH5539 (also APC)
299B99	Edax 99 Switch	184C102	Facit (Euro)(also BTC, Pack Bell, Mitac,Donatec)
336E107	E-filiate #1380207, windows, back-L enter	520D76	Federal APD Powerpad
530C85	Electrocom MDC 890 (also Digicom)	998C104	Fellows Ergonomic w/windows keys KB7903 (also Chicony)
504A51	Electrocom MDT 800 (also Digicom)	108D104	Fellows 99900, KB5911
764E104	Eliminx S-202-12	723D105	Fellows KB3963, EZ Multimedia key (also Chicony)
565C101	Elite SK2000R FCC:GYUR10SK "L" Shaped Enter (also Liteon, Zenith, Ultra,Hewitt Rand)	532D104	Fellows 99902, KB2961
794D104	E-Machines KB2971, Rec enter key	931D106	Fellows KWD805 (Euro), EZ Multimedia
112E104	E-Machines KB2971, back-L enter (also Chicony)	112E104	Fellows 99148/98914/KB2971 (also emachines)
958D110	E-Machines EKB5000 W/rec enter, Multimedia	1958B105	Fellows KB-9938
178E123	E-Machines EKB5190(A), Multimedia, Rec enter	1976B104	Fellows KWD-855
958D110	E-Machines 7800, rec enter (also Chicony)	613C105	Filenet Keyboard
2010B104	E-Machines 5143	729E122	Firefly 171939 - rect enter
1939B104	E-Machines KB0108 - 18 Internet buttons	93B66	Fisher Porter 66 Switch
438B101	Emerson 286 (also Data Gen.,Dasher,Tatung, Fujitsu,Earthstation,Sanyo,Vendex)	923B142	Fisher Provue Desktop
		187C142	Fisher provue Console

P/N	Description	P/N	Description
259C91	Fisher Provox Micro desktop CPN11B8000X042 (also Keytronics)	594E91	Fujitsu Lifebook CP162681, Fcc: EJECNOOB8687
49C113	Fischer Porter DCI System SIX	762E86	Fujitsu Lifebook B142, CPO12888
302C114	Fischer Porter DCI System 6 (EUROPEAN)	829E90	Fujitsu Lifebook E8020
599D108	Fisher Rosemount LK401 P/N 122530-001	561D84	Funkentstort KPT-84, Fcc: IYNKPT-84 Mini
999B101	Focus FK-1001 Compact	802B102	Gamma System(Latin America)
819B108	Focus FK-2000(+)(also Magnatronics)	338B101	Gateway 2000 EO3435(also Keytronics, AGI, DataMax, Mitsubishi,Goldstar, Priemier,Spear Technologies)
26C111	Focus FK-3001 (also Datadesk)	35B101	Gateway 2000 101 Key (also Maxiswitch, Everex, ALR, Opus,Avtech, Easy Data, Texas Microsystems)
817B101	Focus FK-2001 (also CSR,Proteus) (101 Keys,2 Keys on both sides of spacebar)	851B101	Gateway 2000 101 key RT-101+ (SEE HITEK FOR OTHER MODELS)
497C102	Focus FK-2001 (102 Keys,3 keys on both sides of spacebar)	987B124	Gateway 2000 "ANYKEY" Model 2191011-xx Fcc: HWYKEY1 (also Maxiswitch)
52D104	Focus 2001W Fcc:FSQ4VYFK2001 W/Win keys	17D124	Gateway 2000 "ANYKEY" w/window keys FCC: D7J2194-001-XX 2194002
761D107	Focus FK2001 Fcc:FSQ4VYFK2001 Back-L enter Three Extra keys above directional keys	707C125	Gateway 2000 "ANYKEY" (EUROPEAN)
969B130	Focus FK-5001(5 Keys Above Num Pad)	563C101	Gateway 2000 101 Keys 2189013 "Rounded Edges" FCC:D7J2189-001-XXX
198C129	Focus FK-5001(4 Keys Above Num Pad)	583C85	Gateway 2000 Colorbook Laptop C8486SX33 FCC:EF7A232J33
202D104	Focus SK-5002W Fcc: GYUR30SK	701C101	Gateway 2000 2189013-00-006("L" shaped enter)
196C102	Focus FK-6000	700C102	Gateway 2000 2189013-14-001 (European)
864C103	Focus FK-6200 EZ Key FCC:FSQ100138	924C101	Gateway 2000 2194013 (smaller than 563C101)
95D104	Focus FK-6200 E-Z Key w/ windows keys FCC:FSQ100138 4 keys right of spacebar	947C104	Gateway 2000 w/windows keys 2194014-00-002
554C99	Focus FK-7000P w/Trackball FSQ4VYFK7000P	984C104	Gateway 2000 w/windows keys 2196001-00-002 "L"enter key FCC:D7J2196001
203C111	Focus FK-8000	446D104	Gateway 2000 2196002 Fcc:D7J2196001 (Maxiswitch)
198C129	Focus FK-9000(also called 5001)	237D104	Gateway 2000 2196003-XX w/win keys rect enter
53D103	Focus FK7200 E-Z Ball FCC:FSQ101048	337D87	Gateway 2000 Solo 2100 FCC: HFMSQX
93D104	Focus FK7200 E-Z Ball w/windows keys FCC:FSQ101048 4 keys right of spacebar	05D88	Gateway 2000 Solo Port W.Win PP2-P3C
38E108	Focus FK7200 w/Win, Trackball, Back-L enter Fcc:FSQ101048, 3 xtra keys above directional	445D116	Gateway 2000 MULTIMEDIA #7000598, 7001025 #7001211,7001602 Fcc:EO6150US011-C (also Keytronics)
588D126	Focus FK8200 W/Win Keys Fcc:FSQ028058	694D104	Gateway G9900 P/N 7001024 Fcc: GYUR61SK
590D104	Focus FK5200 W/Win Keys Fcc:FSQ811169	878D116	Gateway G9900H,7001603,7001456, Multimedia
51E127	Focus FK9200 EZ Pro Fcc:FSQ918058	645D105	Gateway G9900-2D Fcc: GYUR61SK (Euro) (also Liteon)
461B68	Formeter F2P	666D104	Gateway EO6350US001-C,701049,7001459,7001628
851B101	Fountain 386/20,25	667D98	Gateway M/N KBDNPG005ABWW FCC:CMYKPKQ7119 DESTINATION KEYBOARD & REMOTE
860A131	Foxboro 131 Switch	671D86	Gateway Solo 2500 Portable
155C85	Foxboro PO400QB	829D89	Gateway Solo 2500 W/ Win Keys, Trackpoint
852B102	Fujitsu FKB 4700-102	672D90	Gateway Solo 9100 Portable
438B101	Fujitsu FKB 4700 (also Data Gen, Dasher,Earthstation, Emerson, Sanyo,Vendex,Tatung)	724D89	Gateway Solo 3100 Portable
152D104	Fujitsu FKB4725 w/windows FCC:C9SKB4725	765D82	Gateway Solo 5150 Portable
742D105	Fujitsu FKB4725-662 (Euro) "7" Enter,Win	101E90	Gateway Solo 5300, Windows, Glidepoint
319C101	Fujitsu 3COMM FKB-4707-101	143E96	Gateway Solo 9500, Multimedia, Rec enter, Glidepoint
596B101	Fujitsu 4800	144E90	Gateway Solo 9300, Rec enter, Glidepoint
326B102	Fujitsu Model 260	145E90	Gateway Solo 1100, Rec enter, Glidepoint
114C101	Fujitsu FKB4850-101 N860-4850-T101	246E94	Gateway Solo 1150, Rec enter, Glidepoint
745B101	Fujitsu TO26A/Epson 386XT	948D104	Gateway "Winnie the Pooh" Childrens Keyboard
920B123	Fujitsu Atrium (POS Keyboard)	81E116	Gateway SK9920, RT3602, #7003604, 7004349, Multimedia, Rec enter
654A84	Fujitsu 84 Key(also Radio Shack)	126E104	Gateway SK9921,RT3602,P/N 7002557, 7002739
181C100	Fujitsu N860-4201-T001	141E117	Gateway SK6205H(G), Ergo, Multimedia
195C84	Fujitsu N860-7305-T904(also Epson)PORT.	142E111	Gateway SK9910U, MILLENNIUM Keyboard, Multimedia, Rec enter
337C118	Fujitsu N860-8701-T001(also SUN)	454E94	Gateway 450SX4, M405 Laptop, Rec enter, Glidepoint
370C119	Fujitsu N860-8701-T010-02A(also Sun)	499E105	Gateway SK9921 (Euro) A7" enter
450C101	Fujitsu FKB-4870-401 P/N860-4870-T-401 (also Epson)	519E94	Gateway 600YG2 Laptop, Rec enter, Glidepoint
947B110	Fujitsu N860-4743-T001 (also MAI)	549E97	Gateway Solo 1450 Laptop Fcc: HFS145015318, Rec enter, Glidepoint
940C101	Fujitsu N860-8720-T301 (also Wave)	584E103	Gateway M500B1, 505XL Laptop Fcc:PU5MS2119
51D104	Fujitsu 8720 w/windows keys N860-8725-T601 FCC: C9SKB8720	709E104	Gateway SK-1510, 7004953 - rect enter
455D105	Fujitsu FKB 8720 (Euro) Fcc:C9SKB8720	2033B104	Gateway KB-0401
46C64	Fujitsu N860-1406-T001 Palmcomputer	770E122	Gateway KR0350, fcc:E8HKR-0350
727D107	Fujitsu FKB8730 W/Mousekeys Fcc:C9SKB8730	808E104	Gateway KB2961, KB0447, Rect. enter
874D90	Fujitsu Lifebook E351, Fcc:5BQJPN-25675-M5-E w/ win keys, Rec enter	532D104	Gateway 7005396 (also Chicony)
923D60	Fujitsu M/N PD-KB02, N860-8577-T002	814E93	Gateway M275 laptop
924D60	Fujitsu M/N PD-KB100W, KB9975, Rec enter	931E89	Gateway M250 laptop
989D91	Fujitsu Lifebook L440, Rec enter, Glidepoint	880E89	Gateway M460 laptop P/N 1MA15081898
50E87	Fujitsu FMWKB3A, Rec enter, windows	162A64	General Electric 2030 PRINTER
124E88	Fujitsu Lifebook CPO47430	520E105A/B	General Electric Logiq Book M/N 2349933 A7" enter
125E91	Fujitsu Lifebook CPO47801-01	1977B107	Genica GN-151
226E92	Fujitsu Lifebook P/N CPO82849-01, Fcc:5BQUPN-35271-DT-E, trackpoint, rec enter		
413E92	Fujitsu Lifebook CPO82849-01, 5BQUPN-35271-DTE		
425E90	Fujitsu FKB8738-101, 3 buttons - arrow keys, Rec enter		
535E86	Fujitsu Lifebook CP145814		

P/N	Description	P/N	Description
931D106	Genius KWD805 (Euro), Multimedia,"7" enter	150C106	Hewlett Packard C1408A(Euro)C1417A ABF
299E104	Genius KWD701 win.,back-L enter, (also PC Concepts)	523C102	Hewlett Packard A2840A ABE (Euro,S.A.) Fcc:CIGEO3614 (also Keytronics)
451E87	GoBook II	546C101	Hewlett Packard Vectra VL A2840-60201 Fcc:CIGEO3614 (also Keytronics) C3757-60201,C3346-60201
851B101	Goldstar 116626 (see Hitek -other models)	27C80	Hewlett Packard 95LX/200LX Palm Computer
529B102	Goldstar 5339R (also BTC, Packard Bell, Mitsuma, Tatung, KLH, Hewitt Rand)	749C109	Hewlett Packard C3340-60201 D/M3428 (also Keytronics)
338B101	Goldstar EP3435(also Keytronics, Datamaxx, Mitsubishi, AGI, Gateway, Premier, Spear Technologies)	915C106	Hewlett Packard C3342-60205 C1081CABF(Euro)
922E90	Gold Touch SKR4200U - split keyboard	988C106	Hewlett Packard C3343-60201, EO3619USA
708A112	Graphon G250	20D104	Hewlett Packard 3537 w/windows keys P/N 5182-5521 CIGEO3633, C4725-60201 /3707, Rec enter
554A57	Grid Compass 1109	99D105	Hewlett Packard 3537 w/windows keys (EURO) #5182-5521 FCC:CIGEO3633
83B72	Grid 1520/1530	158D86	Hewlett Packard Omnibook 430
921B77	Grid 1550 Portable	391D116	Hewlett Packard SK-2501, SK2501K Fcc:GYUR38SK Multimedia keyboard (also Liteon)
365C78	Grid 1550 with mouse, portable laptop	459D117	Hewlett Packard SK2501 (euro) Fcc:GYUR38K
982B84	Grid 1720 Portable(also Panasonic, Tandy)	466D104	Hewlett Packard SK2502 C4732-60101 D5728,Fcc: GYUR41SK
557E105	Gyration Mobile Keyboard Fcc:JJ4-GP221-001, GP1190, Windows, Multimedia, Rec enter	837D104	Hewlett Packard SK2502-C C4739-60101, Rec enter
833E104	Gyration GC1105, GC15CK Fcc:JJ4-AS00900	536D105	Hewlett Packard SK2502 (Euro) Fcc:GYUR41SK C4735-60108, EO6333KLA
36C101	Handok-101 KB5191(also Leading Edge, Chicony, Kris Tech, Auva)	862D105	Hewlett Packard SK2502-C (Euro) C4739-60108
672E65	Happy Hacking Lite II keyboard, KB-0010, rec enter	467D119	Hewlett Packard SK2505, Multimedia II Fcc: 5182-8850
19B93	Harris F178-13E(93 Switch)	839D119	Hewlett Packard SK2505-C P/N 5183-7376 W/Win , Multimedia, Rec enter
20B109	Harris F178-12E(109 Switch)	566D120	Hewlett Packard SK2505 (Euro) Multimedia
112B122	Harris F-180-11E(122 Switch)	404D86	Hewlett Packard Omnibook 425 w/win keys Laptop FCC:B94F-1033
214B122	Harris 122 RK335(Also Lee Data Data, Dell, Idea, Memorex)	448D88	Hewlett Packard Omnibook2000CT Fcc:B945500
301C122	Harris Adacom PC122US(also Hitek, Harris)	513D104	Hewlett Packard FDA-104EB Fcc:F42FDA-104EB
467C122	Harris Adacom F190-22T	574D105	Hewlett Packard FDA-104EB (Euro) Fcc:F4ZFDA104EB
71A101	Hazeltine 80 Model 20	512D116	Hewlett Packard FDA-116CA Fcc:F4ZFDA-116CA
98A108	Hazeltine 80 Model 30	577D90	Hewlett Packard Omnibook 3000CTX W/Glidepoint
309A83	Hazeltine Corstar Model 20	859D90	Hewlett Packard Omnibook XE, Win, Rec enter, Glidept.
310A104	Hazeltine Corstar Model 30	908D93	Hewlett Packard Omnibook 4150, Glidepoint, Rec enter
991B89	Hazeltine TC101005-1	589D104	Hewlett Packard C4735-60101 D/M:3818 Fcc:EO3633KU5001-C, KB9970, C4744-60101
992B94	Hazeltine TC401116-1	378E104	Hewlett Packard KB9970, C4744-60201 (Same as above but keys lower)
584B101	Headstart/Magnavox KKB5181(also Chicony, Hyundai, ARC, Identity)	678D107	Hewlett Packard RT2858TW 4-1/8" Spacebar 5183-6247, 5125 (also Hitek)
529B102	Hewitt Rand HR 5339R(also BTC, Packard Bell Goldstar, Mitsuma, Tatung, KLH)	689D107	Hewlett Packard RT2858TW 4-5/8" Spacebar, 5125
565C101	Hewitt Rand SK-2000R FCC:GYUR10SK (also Liteon, Zenith, Ultra, Elite)	679D108	Hewlett Packard RT2858TW (Euro) 5183-6249
*****	All HP (Hewlett Packard - see also Compaq)	696D105	Hewlett Packard C4735-60302, D/M 3830 (Euro) Fcc:EO6333KCF201C
05C108	Hewlett Packard/Apollo A1630-82001	728D117	Hewlett Packard C4734-60501, SK2501A Multimedia
54C106	Hewlett Packard/Apollo 7121 Rev 1	888D117	Hewlett Packard SK2511A, C4742-60101 MultiMedia
769A55	Hewlett Packard 71B	15E118	Hewlett Packard SK2511A (Euro), Multimedia
45A92	Hewlett Packard 85	748D111	Hewlett Packard #5129, P/N 5183-7399 Multimedia 3 Keys to left of spacebar are same size
146A71	Hewlett Packard 86/87A	877D111	Hewlett Packard RT2856TW, P/N 5183-7399 Multimedia Left Control key larger then 2keys to right.
772A76	Hewlett Packard 110	749D112	Hewlett Packard #5129 (Euro) "7" enter Multimedia
438A107	HP 150/2392/2397/46010/46020/46021	950D126	Hewlett Packard #5183-9980, SK2506, 6511-S, RT5302, 5184-9648, Multimedia
459C107	Hewlett Packard 46021B #ABA	949D127	Hewlett Packard P/N 5183-9972 (Euro), Multimedia
52C106	Hewlett Packard 1401A 700/43	47E91	Hewlett Packard Omnibook 6000, 6100 Touchpad
336B106	Hewlett Packard 1402A/ C1421A	138E111	Hewlett Packard SK2530, (Euro), P/NC4759-60108 "7" enter, Multimedia
415B122	HP 1404A/1410A(also Decision Data)	165E125	Hewlett Packard SK2560, 5181, 6511-Z, 5185-1596, 5187-0341 Multimedia, Rec enter
801B102	Hewlett Packard 1405A (Latin America)	168E126	Hewlett Packard SK2560 (Euro), Multimedia, "7" enter
232C101	Hewlett Packard 1405B/C1429B	189E125	Hewlett Packard Pavilion #5308 (Euro) #5185-2411
341C102	Hewlett Packard 1405B(European)C1429B	245E98	Hewlett Packard Omnibook XE3, rec enter, glidepoint
34A68	Hewlett Packard 2621A	294E123	Hewlett Packard SK2565, #5308, rec enter, multimedia
219A100	Hewlett Packard 2622A/2623/2624/2627	295E110	Hewlett Packard SK2530, SK2585, 6511PK, C4259-60101 rec enter, multimedia
486A100	Hewlett Packard 2628	298E107	Hewlett Packard SK2502C, C4739-60124, (Euro),"7" enter
118A105	Hewlett Packard 2640/2645	316E107	Hewlett Packard KB9970 (Euro), C4744-60228 "7" enter
640C105	Hewlett Packard C3342-60201/C3344-60201, #105946-01 EO3616TIOSABA(also Keytronics)	337E72	Hewlett Packard Jornada 720 laptop, Fcc:5WWSNG-35048-DT-E
100A41	Hewlett Packard 3390A		
518A46	Hewlett Packard 3392A		
126A71	Hewlett Packard 9816 Series 200/98203A		
303A105	Hewlett Packard 9825-B		
490A106	Hewlett Packard 98203B/805 Ext(European)		
702A105	Hewlett Packard 9826		
691A103	Hewlett Packard Vectra 46030A, C1406A		
969A101	Hewlett Packard Vectra Enh/ C1429A, C1405A(US)		
98B109	Hewlett Packard 700/92/93/94/60/1400A		
144B105	Hewlett Packard 700/44(also Texas Instr.) C1417A/C1408A		
966B115	Hewlett Packard 9000/HP9020A		

P/N	Description	P/N	Description
380E96	Hewlett Packard Omnibook XE4100, CRVSA-02TI-60 Rec enter, windows, glidepoint	670C102	Hitek RT-102 119691-013 FCC:AQ6ZG-RT687XT(EURO)
516E107	Hewlett Packard 5107, P/N 5187-1734, Fcc:E5XKB5301 Back-L enter, (also BTC)	521C122	Hitek 117543,116387 122 keys (also I/O Devices) PC122 119954-00
522E128	Hewlett Packard 5219 (Euro) Fcc:E5XKB5209	538C101	Hitek RT-6671 119088-001,119489,119967(also Adds, Esprit) FCC:AQ6Z-RT687XT "L" Shaped Return Key" AQ6-CYPRESS RT687ST 119689 RT-6656(+)/RT6256T
396E112	Hewlett Packard KB9009, DC167B (also Compaq)	508C102	Hitek RT-102(+)/RT6251 (France,Euro) 118423-001 FCC:AQ6ZG-RT6271T
638E104	Hewlett Packard SK2875, KB0316, rec enter (also Compaq)	722C101	Hitek Rt-8755C+ P/N 120022-201 FCC:AQ6MAPLEZ15
639E116	Hewlett Packard 5183, KB-0228, 5187-1767, Fcc: E5XKB5183	802C122	Hitek 118997-001 (also Idea)
1672B107	Hewlett Packard 5201 (also BTC)	898C106	Hitek 120049-001 (also Adds)
730E109	Hewlett Packard KB0316 (Japanese) (also Philips)	936C101	Hitek 230851-001C (also AST, Liteon)
731E105	Hewlett Packard KB0316 (German) (also Philips)	913C101	Hitek 120340-002,184315-101 FCC:AQ6-CypressC15 (also Compaq) Rect. Enter Key
748E106	Hewlett Packard KB0316 (Korean) (also Philips)	957C104	Hitek RT-6655/6656TW w/window keys FCC: AQ6MTN4XZ15 Rect. Enter KEY (also AST, Liteon, Compaq)
1960B104	Hewlett Packard 5209, KB-0218, 5187-6105	124D104	Hitek RT-4958TW (US)w/win Keys rect. enter key Fcc:AQ6MTN7Z15 (also Dec, AST)
1790B104	Hewlett Packard 5308	91D105	Hitek RT-4958TW (Euro)w/win keys 11121166-013 Fcc:AQ6MTN7Z15 (also Dec)
1999B104	Hewlett Packard 5219URF	125D104	Hitek/NMB RT6856TW #247429 w/windows keys RT6600W,rect enter key FCC:AQ6CYPRESSZ15
881E127	Hewlett Packard 5219CRF, 5187-7076, Fcc: 5XKB5219CRF, Rec enter	262D106	Hitek/NMB RT6856tw (EURO)FCC:AQ6MTN4XZ15
757E06	Hewlett Packard iPaq H3600 series	232D105	Hitek/NMB RT8255C+ w/win keys/split-spacebar RT-8200W,FCC:AQ6-OAKZ15 121296-001
838E108	Hewlett Packard NX9600	565D104	Hitek RT8255CW(+) W/Win, Full Spacebar, Fcc:AQ6-OAKZ15 (also NMB)
826E121	Hewlett Packard 5187, 5187-7583, 5187-7584, RT7H10	322D105	Hitek/Hurricane Systems RT-2257WLA (EURO) w/winkeys FCC: AQ6MTN71BZDIP (ALSO COMPAQ)
812E121	Hewlett Packard 5187 (Euro) Fcc: E5XKB5187, p/n 5187-8430	326D104	Hitek RT-2257WLA w/win keys(also Compaq) RT-2200W,FCC:AQ6MTN71BZDIP
831E85	Hewlett Packard Tablet PC TC1100	405D102	Hitek RT-102T Model 122421-001,Rect enter
860E97	Hewlett Packard NC6230 laptop	463D104	Hitek RT-5158TW Fcc:AQ6-8Z15, #122546-001
890E92	Hewlett Packard NC8000 Laptop	641D104	Hitek RT915CTW CONCERTMASTER (Also Compaq)
906E75	Hewlett Packard Jordana 728 mini keyboard	102E118	Hitek RT9258TW, Fcc:AQ692K15, Rec enter, Multimedia
212B15	HHT500	203E104	Hitek RT2900TWL, Fcc: AQ6-RT2900
695A101	Hirez 100 XL	785E103	Hitek RT2300, AQ6-2300
571C105	Hitachi Flora 3010/KB1100	752E87	HK mini keyboard HK-2208
224D83	Hitachi C-100T Model720 w/trackpoint Laptop p/n C1042A-001, FCC:MMD-PCK-5NS01-01	561C102	Honeywell 102WN63S-7EN (also Zenith) Fcc:GJK-101WN5 (EURO)
619D84	Hitachi MX-133T port. Fcc:HFSMPX	920A122	Honeywell 122 Switch (also Telex)
160B84	Hitek AT 84 keys 112980-005 (also Vendex)	214B122	Honeywell 122 RK335 (also LeeData, Harris, Idea, Memorex)
367B101	Hitek 101(+) 115039-002 (also Arch Rival 386SX)	784B92	Honeywell 92 key
154C108	Hitek 117652-001 N-108LK(also NCD)	483B115	Honeywell Bull HD57
78C101	Hitek 116545-001 (also Liberty)	10B101	Honeywell 101 (also Microswitch) 101RX43S-79
70C106	Hitek 117155-101 (also Tandem,Adds,NCR,Hitek)	227B83	Honeywell 83 Switch
129C105	Hitek 117085 (also NCR)	327B108	Honeywell 108 Switch
851B101	Hitek RT-101(+) 117342-011/117532 rev.c,d, 118057 117342-001 rev.B,C,D/117926/116920-001, 117994 CMA650F2/AQ6MEMB-74004,RT-6251T,118420, 117994-001,118413-002,118054-011,118614-001 119616-001,RT6255T,AQ6ZGRT6271T,AQ6RT101LC RT-8200,RT-8255C,AQ6ZRT827XX,AQ6-OAK-Z15 (also NMB,Everex,Gateway,Phillips,Astrix,Matrix, DTK, Cumulus,Fountain,Goldstar, Model America)	352A101	Honeywell TDC 2000(\$30 SET)Incl.353A44
652B101	Hitek RT-101(+)116305-003,117825 AQ6RT7251 (also Micronics, Arch Rival)	201B108	Honeywell 7814
177C105	Hitek 116429-001(also Liberty,Tektronix)	976B105	Honeywell 105ST-13(also Bell & Howell)
188C122	Hitek 810-12966NMB(also Idea,NMB)	726A116	Honeywell PC8/916 (also NCR)
782B122	Hitek 122 116528 (also Idea)	03C107	Honeywell M22 (also Bull,Memorex)
231C101	Hitek 117700-001 (also CompuAdd,Memorex/Telex)	519C74	Honeywell 74RX33S-3E (also Dec)
711B101	Hitek 116130, N101PS, 117541 (also NCD,Northern Telecom,APC)	151C101	Honeywell 101RX33S-6E(also Dec,Mem-Telex)
247C101	Hitek 141648-101 (also Compaq)	354C101	Honeywell 101WN63S-8E(also Dec,Tektronix)
290C102	Hitek 118742-014 Rev.B (also Compaq) RT-102 FCC:AQ6MEMB-74004(European S.A.)	355C101	Honeywell 101RX43S-71E (also Dec)
622C101	Hitek 160648-101 (also Compaq, Mitsumi)	51C84	Honeywell 84RX435
301C122	Hitek 118285-101,118997-001 (also Harris,Idea)	53C101	Honeywell 101RX435("L"shape return)
774B101	Hitek CMG65001(Also AST,Versyss)	14C101	Honeywell 101WN (also Dell)
994A101	Hitek RT-101FT (also Wells America,Earthstation) AQ659ZRT-101A,115034-0019 (Also Televideo)	493C102	Honeywell 102WN (Euro)FCC:GJK102RX-6
477C101	Hitek 119135-001 FCC:AQ6ZG-RT-667XT, 120340-002 (also ALR,DTK,Duracom) 119249,119976, AQ6ZGRT667XT "L" Shaped Enter Key AQ6CYPRESS RT-6855(+),RT-6800	305C122	Honeywell 122RX-31S-1E(also Dec.Data)
478C101	Hitek 119459-001,119127-001"Rectangular Enter key" FCC:AQ6ZG-RT-687XT (also Compaq, AST, ADDS, AQ6MTN4XZ15,119999,RT-6255(+),RT-6652T	344C102	Honeywell 102RX-31S-1E(also Dec.Data)
		383C101	Honeywell 101WN-63S-11E FCC:GJK-101WN-5 (also Zenith)
		411C101	Honeywell 101RX43S-72e FCC:GJK-101RX-5 (also Zenith)
		997C102	Honeywell 102RX-43S-222E
		300B84	Hotek 84 Switch KB084
		233C102	HQK RB-2001 (Taiwan)(also Cumulus,Identity)

P/N	Description	P/N	Description
	Fcc:HQK2VHKEYMOUSE	513B122	IBM 3476/3471/3477 1397852,1394100,1395662 1394308,1395160,1397000,1397050,1395660 1394801,1395661,1397953,1394167 (Lexmark)
64D103	HQK 103 FCC:BITS 6001 (also Ultra)	101C111	IBM 4683 Computer P.O.S.terminal
73D102	HQK RB2001 (102 keys)	789A83	IBM 5251
174D105	HQK TC9500 w/win FCC:HQK-BITS-6001 Pencilbar	308C103	IBM 3151/3152/3162/3163/3164 (EUROPEAN) 1390637, 103 KEYS
175D106	HQK TC9500 w/windows (EURO) HQK-BITS-6001	513C84	IBM 1397901 Mini-Keyboard model M4(also Lexmark)
298D105	HQK BITS-6001 w/win keys (also PC Concepts)	798C87	IBM 1379590 Mini-Keyboard Model M4-1 w/trackpoint FCC:IYL1379590, PS-2E
389D106	HQK 9001 FCC:HQKBITS9001 Turbo-trak w/win "L"enter Single size left shift key	616B125	IBM Polydent (European)
425D105	HQK 9001 Turbo-trak same as above full size left shift key	889B65	IBM Wheelwriter III "TYPEWRITER"
456D106	HQK KB-9001R(+) Fcc:HQK BITS9001 pencilbar single shift keys left and right	893B59	IBM Selectric III "TYPEWRITER"
508D104	HQK KB-8801R(+)/Turbojet w/win (EURO & US)	894B57	IBM Selectric II "TYPEWRITER"
686D109	HQK TurboTrak KB9002R3+ W/Win Keys	393A62	IBM PC JR.OLD STYLE
810D108	HQK Turbo XWING KB3001RE+ #161Z108	553C62	IBM 7527 Data Collection Terminal
811D109	HQK Turbo XWING KB3001RE+ #161Z109	548C50	IBM POS model 100
161E108	HQK BITS9001, Back-L enter (also TurboTrak)	785C18	IBM PS-2E KEYPAD ONLY 1379550 model M4-1
211E132	HQK KB9801R+, Multimedia, Back L Enter	39D101	IBM Aptiva FRU-06H5305 FCC:J2S101WN-3
314B107	Human Design System #85-1A	62D102	IBM Aptiva (EURO) FCC:J2S101WN-3
167B107	Human Design System 107 Switch 87-6A	160D104	IBM KB8923 FCC:E8HKB5923(also Chicony)
355E90	Hyperdata Notebook P14N, win, glidepoint	986C101	IBM KB6923,6323 FCC:E8HKB5323 (also Chicony)
639E116	Hyperdata T2C Laptop	151D102	IBM KB5323 (Euro) (also Zenith,Chicony)
947A102	Hyundai 102 (also BTC,Minta,Packard Bell)	916C104	IBM KB6923,6323 w/windows (also Chicony)
584B101	Hyundai 286N/386D/386SE/KB5181(also Identity, ARC,Chicony,Magnavox,Headstart)	220D105	IBM KB8926 (Euro) FCC:E8HKB5923 w/win keys (also Chicony)
433B139	IBM Matrix	215D92	IBM SUREONE 4614 Formed Keys
138A83	IBM Standard P.C.XT/5531/5291	216D12	IBM SUREONE 4614 Universal
470B104	IBM 3290	411D110	IBM PS-2 w/trackpoint & trackball
434B121	IBM 3180-1	385D112	IBM PS-2 w/trackpoint & trackball (Euro)
628A101	IBM ENHANCED P.C./PS-2 Model 30/50/60/80 1397651,1395100,1390120(also Dell,Lexmark) 1392090,1390131,1391401,1331109,1378162,1397735 52G9658,52G9700,82G2383,82G3278,IYL60g3571 42H1292, 71G4644, 1395162	502D116	IBM KB-7993 MULTIMEDIA W/Win
628A101	IBM Valuepoint PS 2, 1394950	751D117	IBM KB-7993 (Euro) Multimedia, Win Keys
672C109	IBM PS2 w/trackball 139907 FCC:IYL1398150 (also Lexmark)	548D104	IBM KB-7953 KB9910 W/Win Keys
821C102	IBM PS-2 w/trackpoint P/N 06H4173 Model M13 92G7461, FRU-06H4842	695D105	IBM KB-7953 (Euro) W/Win Keys
400A84	IBM P.C. Original AT	269E103	IBM KB-9910 (Euro) "7" enter
965A84	IBM Model 25 (Space Saver)1391472 1370475,1395682,1392934	725D107	IBM KPD8923 W/Win Keys & Trackpoint
723B101	IBM PS-1 1395300,42H0468,8131276,73G4614 Fcc: IYL1398418, 3153	993D119	IBM KB9930 Multimedia, rec enter
946B102	IBM PS-1 (S.A.)(European)	985D120	IBM KB9930 (Euro), Multimedia
76D104	IBM PS-1 (EURO) (104 keys)	02E85	IBM Spacesaver Model 25, "7" enter
725A102	IBM PS-2 European Version(102)AT3/30/50/60/80 1391413, 1391506	18E88	IBM Thinkpad 760ED, Type 9546, Fcc:ANOGCF2704AI Rec enter, trackpoint
690A88	IBM Laptop Portable	20E81	IBM Thinkpad 240, Type 2609, Fcc:409TAI-25871-M5E Rec. enter, trackpoint
316C84	IBM PS-2 L40 Laptop Portable	82E96	IBM Type 2621, Rec enter, Wins.
490C87	IBM Portable Laptop 350 Type 2618 FCC: AN02618M486	88E94	IBM Thinkpad A20, Type 2628, T23
731C88	IBM Thinkpad 360/365 Notebook Type 2620	100E106	IBM KU-9958, SK8811, 32P5000, SK8806 rec. enter
840C82	IBM Thinkpad w/Trackpoint 2603-17N FCC:IYL2603	305E107	IBM SK8811 (Euro), "7" enter
444D88	IBM 560 Laptop W/ Trackpoint	215E104	IBM/Unicomp UNIOP46, PS-2 w/windows, Rec enter
465D88	IBM Thinkpad 380D Type2635 Fcc:ANO9611TBOON	264E115	IBM M9, P/N 92F6271, win, c/c reader, "7" enter
690D90	IBM Thinkpad 380D (Euro)	281E119	IBM SK8805, SK8809, rec enter, multimedia
755D89	IBM Thinkpad #600, Glidepoint, rec enter	360E120	IBM SK8805, SK8809 (Euro) A7" enter multimedia
854D89	IBM Thinkpad #390 Type 2626 W/Trackpoint	297E94	IBM Thinkpad A22E, Type 2655, trackpoint, rec enter
869D91	IBM Thinkpad #1412 W/Win, Trackpoint, Rec. enter	340E102	IBM Thinkpad A30, A150, type 2652, Multimedia Fcc: ANOVNCBDC8021B
162E96	IBM Thinkpad #1161, Rec enter	431E96	IBM Thinkpad R-31, Type 2656, Trackpoint
632B102	IBM 3151/3192/3162/3163/3164 102 keys 1390653,1395665,1390670,1392595 1390940,1386304,1390606	318E107	IBM M-13, P/N UNI04G6 (also Unicomp)
610A87	IBM 3178 6052101	416E94	IBM KPH0035, Rec enter, Trackpoint
67A87	IBM 3101/3278 w/PF pad	421E104	IBM KB-0225, 32P5100,SK-8820, 89P8300 31P7415 Rec enter
560A75	IBM 3101/3278 wo/PF pad	478E105	IBM KB-0225 (Euro), A7" enter key
711A101	IBM RT	504E98	IBM Thinkpad R40, Type 2681, Rec enter, Trackpoint, Glidepad
533A122	IBM 3161/3179/3180/3270(Pyramid keys) 1390238, 82G2383,82G3278	550E98	IBM Thinkpad T40, R51,T42 Type 2373, Type 2888 Trackpoint
814A122	IBM 3191/3192/3196/3197(Flat) 1390572,1395660,1390702,1390576,1390876	551E98	IBM Thinkpad T30, Type 2366, Glidepoint, Trackpoint
386B104	IBM 3192/3472 (104 Switch)	564E96	IBM Thinkpad T20, Type 2647
		624E96	IBM Thinkpad G40, Type 2384-32U
		755E114	IBM SK8815, 89P8800
		761E114	IBM SK-8835, rec enter, glidepoint
		825E97	IBM SK8845 Thinkpad
		930E96	IBM Thinkpad X41- Tablet PC Type 1867
		135B100	ICL M91
		683B122	Idea Courier 12000 (also Memorex, Telex)
		214B122	Idea 701626/27/28 (also Lee,Harris, Honeywell,Memorex)
		782B122	Idea 116528 IDE-K 16428 (also Hitek)
		987A110	Idea 701146-004 (also ITT 1778)

P/N	Description	P/N	Description
188C122	Idea/NMB 810-12966nmb(also Hitek,NMB)	787E100	Keysource International KSI1401 (also Wombat)
388C103	Idea UK English 103 PT#B13707-002(Euro)	907E120	Keys U See P-21 (Also Scorpius)
301C122	Idea B12917-002(also Harris,Hitek)118285-101	72B84	Key Supply 84 Switch
802C122	Idea B12917-002/118997-001 (also Hitek)	860B102	Keytec Mony Data (Brazil)
54D102	Idea 102	718A84	Keytronics 5150
233C102	Identity HQK-RB-2001(also Cumulus,HQK)	537A99	Keytronics KB5151/52 EO3354051(also Sperry)
584B101	Identity KB5181 (also Chicony,Hyundai,Magnavox Headstart, ARC)	644A87	Keytronics KB5153
135C101	Identity ZBKB101SR (also Monterey)	802A101	Keytronic KB 101/MB101/VA101 E03417 (also,Rita, US101,AT&T,Arnet,Samsung,)
735B105	IDT-105	84B101	Keytronic 101(+) EO3435 (L Shaped Enter Key)
450E117	Ifree GL3001, Fcc:OR7GL3001, Multimedia, Trackball	465C101	Keytronics KB-101(+) "L" Shaped enter Key Fcc:CIG8AVEO3417
859E114	Illuminated Keyboard KB606SL/BK	338B101	Keytronic EO3435/XT/AT- Rec enter, (also Gateway,AGI Datamaxx,Mitsubishi,Goldstar, Premier,Spear Technologies)
958D110	Inland KB9908 (also Chicony)	847B101	Keytronics EO-3600Q KT2000 (also AT&T)
591E104	Inland Keyboard	153C103	Keytronics EO 3608Q-FC(also AT&T)
265C105	Insight VT-220 KM-0220 (Euro,UK)	131C102	Keytronics EO-3608Q306E(also AT&T)
192A101	Intecolor (ISC) F8000/F8000G/F8001R/8801R/8800/ Intecolor 3800 (101 Switch)	848B101	Keytronics EO-3601QF1/E03601QL(also AEG)
470A117	Intecolor (ISC) (117 Switch)	215C101	Keytronics/DFI EO3601E/3601EL Fcc:CIGEO3600
527A112	Intecolor (ISC)(112 Switch)	215C101	Keytronics FLASH 101/KT2000
571A107	Intecolor (ISC) CT220 (107 Switch)(also Paramax)	677B102	Keytronics EO3602 KT2000 (EURO)
25C114	Intecolor 103314-CT220	236C102	Keytronics EO3602Q(Euro)(also AT&T)
328E113	Intel M/N ISO11469, Fcc: EJM123112960 Multimedia, rec enter	971A102	Keytronics Switch (Euro UK)EO3418
122D105	Interex model MAC105A FCC:F2Q90105ADB	89B101	Keytronics EO3443(also Unisys,Dec)
999D108A&B	Interfaces KB-10, Fcc:L2PWPDP1BBC, Glidepoint	62B122	Keytronics 122 Switch/KB 3270 PLUS FCC:CIG8AVE03448
37C101	InterFatron 101 IF	177B23	Keytronics Adder Pad old model
541D132	Interfatron "IFKEYMAC" Fcc:LANPROXPROX2	641B23	Keytronics Adder Pad EO3218XTAT-1
526B85	Intergraph Low profile #FT1S0380B	484B105	Keytronics Mac Pro
07C51	Intermec 1700	228C106	Keytronics Mac Pro (Eurorean)
622E80	Intermec 6651	436B102	Keytronics Quicksilver
291A79	Intersil ISB 80-02	606B85	Keytronics Switch 85
388D105	Intertec/APC NBK-2104S/C #875644 (EURO) Fcc: GOGAPC-21	943A101	Keytronics 101-1 (E03370)(also AT&T,Radio Shack,Phillips)
617B122	I/O Devices Model 1181	814B109	Keytronics EO3556051 (also Pitney Bowes)
521C122	I/O Devices 2596(also Hitek)	106C126	Keytronics EO3556054 (also Pitney Bowes)
698C102	IPC Dynasty Model IPC7849R(euro)(also BTC)	989B84	Keytronics Notebook Portable A4 UO4003001
491B100	ISC Systems Model 4900	908B84	Keytronics KB5184WP
763B12	ISC model 6330 Keypad	201C85	Keytronics Port.EO4006002US (also Memorex/Telex)
556C101	ISNJK-258 (made in Malaysia)	259C91	Keytronics EO3546051 (also Fisher)
386C101	ISNJ-168 (also Sunshine,NTC,NanTan)	271C102	Keytronics EO3417202 (also AT&T)
291B101	Jade 101 SK-8801(also Liteon, Computrend,KLH)	272C98	Keytronics EO3555001 (also AT&T)
518C101	JKB-6151B (also SR-9151B)	295C100	Keytronics KBTRAK101 M/O#092895-01 Fcc: CIGTRAK101 w/Trackball
811A84	Kaypro P.C. (also BTC)	635C101	Keytronics KBTRAK010SV (EURO) w/trackball FCC:CIGKBTRAK-101
168A76	Kaypro T-2/T-4	296C101	Keytronics KBTRAK-PRO M/O#089155-03 FCC: CIGTRAKPRO
523E109	KB-122 Fcc:D840902 Back-L enter	317C101	Keytronics "Eurotech" M/O 092355-01 EO3624E, EO3636US001-N, Fcc: CIGEO3600 (also Data Gen.)
585E107	KB-1307	347C102	Keytronics "Eurotech 102" (European) EO3602ESV DOC-102
581E104	KB-6 (also Kensington)	758B106	Keytronics M/N EO359400,M/O081009 (Also Data General)
916C104	KBD-WIN95 Fcc:E8HKB5923	504C101	Keytronics EO5000 M/N 096025-04 FCC:CIGEO5000
742C102	KBM-102 FCC:J6G-KTIC-KBM102 (also SIIG)	428C102	Keytronics EO5002FR (Euro)FCC:CIGEO5000
685D104	KDS MCK600W Fcc: KXJMCK701W (also Ortek, PC Concepts)	520C138	Keytronics #501013528 FCC:CIG8AVEO3417 (also AT&T)
840B95	KEB 95 Key (European)	543C85	Keytronics EO4006US FCC:CIGEO4006
939C105	Kensington #64330 Mac (also Macally)	523C102	Keytronics EO3614SP (Euro,S.A.) FCC:CIGEO3614 (also Hewlett Packard)
124D104	Kensington #64340 (also Dec)	546C101	Keytronics EO3614US (also Hewlett Packard) FCC:CIGEO3614
581E104	Kensington 64340A, 64340HD, Back-L enter	567C28	Keytronics Abacus Mac KEYPAD M/O 104203-02
696E104	Kensington 64331, K64338 Key layout Pyramid shape, Back-L	640C105	Keytronics EO3616TIOS ABA (also Hewlett Packard)
849E104	Kensington K64350	694C84	Keytronics Block Keyboard
336E107	Kensington K64370	739C104	Keytronics Natural Keyboard(also Microsoft) M/N EO3786US FCC: CIGEO3786
850E123	Kensington K64333	745C105	Keytronics EO2968053 (also Bell & Howell)
1970B104	Kensington Comfort Slim K64332	749C109	Keytronics EO3617US M/O 53832418(also HP)
1888B107	Kensinko MCK-2000 (also Ortek)	757C101	Keytronics Protouch 5105 FCC:CIGEO5100
628C102	Keyboard Computer KC-286 (Euro)	762C107	Keytronics EO3470KTC FCC:CIGEO3470
408C73	Key Communications KBAK9448A-250042	780C102	Keytronics M/N 5102FR FCC:CIGEO5100 (EURO)
864D104	KeyPlus KB121 Fcc:D840902 Back L-enter		
656D139	KeySource International KSI1292 POS (Euro)(Wombat)		
657D159	KeySource International KSI1290A POS (Euro)(Wombat)		
804D103	Keysource International KSI2196, SKR1196WT6A		
805D160	KeySource International KSI1290 W/ CC Reader		
242E120	KeySource International KSI8500, rec enter		
573E160	KeySource International KS11290-A (also Wombat)		
618E100	KeySource International KSI-11961, Fcc:GJJSWK8095WS		

P/N	Description	P/N	Description
915C106	Keytronics EO3616FRABFA M/N 106092(also HP)		
890C104	Keytronics KB101(+)-C w/windows keys "L" enter key FCC:CIGKB101PLUS		
891C104	Keytronics KB101-C w/windows keys rect. enter key FCC:CIGEO3418		
23D104	Keytronics EO3601QL-C,EO3601QLPS2-C W/Win KT2000 "L" enter key FCC:CIGEO3600W		
31D104	Keytronics 3600QL-C w/windows keys rect. enter key FCC:CIGEO3600W		
29D104	Keytronics Eurotech-C,LT-DESIGNER Rec Enter, Win FCC:CIGEO3600W		
30D104	Keytronics Eurotech EL-C w/windows keys 3601ELCN-C "L" enter FCC:CIGEO3600W		
19D104	Keytronics EO3602-ELSV-C w/windows keys Eurotech-FC-C,Eurotech-SP-C (EUROPEAN)		
77D105	Keytronics 3602QFR-C (EURO)w/windows		
75D105	Keytronics EO6102FR-C (EURO)w/windows		
100D104	Keytronics Connectkey-C w/windows keys LT-CLASSIC double backspace, backward "L"Enter FCC:CIGEO6100		
112D104	Keytronics EO6101D-C , KT-800, Tag-A-Long FCC:CIGEO6100, back, I enter, win keys (Toshiba)		
165D104	Keytronics Lifetime LT-WIRELESS "WL" EO62051R-C		
166D104	Keytronics Lifetime "LTP" w/touchpad M/N EO6230US201-C		
167D104	Keytronics Lifetime "WLTP" w/touchpad		
168D104	Keytronics Lifetime "WLTB" w/trackball		
169D104	Keytronics Lifetime "LTTB" w/trackball Model # EO6205T-BHW-C		
433D107	Keytronics Lifetime Trakpro Touchpad SV (EURO) w/window keys		
431D108	Keytronics Lifetime LT Trackball SV (Euro) w/window keys		
186D101	Keytronics PCXAL-GA FCC:CIGEO36004(also Dec)		
226D105	Keytronics 6100Z FCC:CIGEO6100Z (Euro)		
368D104	Keytronics KT800 Rec enter FCC:CIGEO6100Z		
445D116	Keytronics EO6150US011C MULTIMEDIA (Gateway)		
551D110	Keytronics (Voyager) modelEZ-1000 W/Win		
552D104	Keytronics (Pilot)Model#EO5305RS Fcc:FKD46AK280W (Also Monterey)		
578D105	Keytronics K280 (Euro) Fcc:FKD46AK280 (Also Monterey)		
553D104	Keytronics EO5305USo-15C, Fcc:FKD46AK288W (Also Monterey)		
617D105	Keytronics EO5305 (Euro) Fcc:FKD46AK288 Also Monterey		
649D101	Keytronics Clientec		
666D104	Keytronics EO6350US001-C P/N7001049		
884D104	Keytronics F-Scan-KSC (FS/SC-K) With Windows, Trackpoint, CC Reader		
885D104	Keytronics F-Scan-K001US (FSCAN), EO3812US001, With Windows, Trackpoint		
886D104	Keytronics M/N EO3634K1USNP-C, S-Card-001US With Window keys, CC reader		
77E123	Keytronics KB5331, EO5351, M/N EO5331USIMM-C, Multimedia, Back L enter		
371E104	Keytronics EO5366BTOPS-2C, Fcc:FKD46AK5300 (Also Monterey)		
495E120	Keytronics EO4601-C, Multimedia, back-L enter		
496E104	Keytronics EO4601-C, Win keys back L enter		
950A101	Kimtron Enhanced		
291B101	KLH SK8801B (also Liteon,Jade, Computrend)		
529B102	KLH 101 Plus(5339RO)(also Packard Bell, BTC,Goldstar,Mitsuma,Tatung,Hewitt Rand)		
1865B105	KM2601/3501		
935B102	KMB 88102 (S.A.)		
57B73	Kodak Ektachem 700/UK102		
918B101	Kodak Ektachem 500/700C/550/750 (also AID)		
423C102	Kodak Ektachem 500/700C/250(also AID)		
721C102	Kodak APC(EURO)FCC:E8HKB-5311(also Chicony)		
347C102	Kodak Ektachem Analyzer model #9501RC#250		
939B84	Kontron IP Lite Portable		
177C105	Liberty 116428-001(also Hitek,Tektronix)		
598C102	Liberty UK 102 PC (Euro 102)		
36C101	Kris Technologies KB5191(also Chicony,Handok,Auva,)		
659D104	KTX KB9000 Fcc:LFCACEKEY1 (also ACEKEY)		
313C101	Kurt Check SR-8151B FCC:FPWSR-8151B996B59 Kustom Electronics MCT-30(Mobil term)		
654B16	Kustom DXT Mobil terminal keypad(upper)		
653B56	Kustom DXT Mobil Terminal Keyboard(lower)		
415E124	Labtec Y-SN28 (also Professional)		
2027B104	Labtec Y-SM46		
585E07	Labtec Y-SR47 (also Logitech) 867307-0403		
864E104	Labtec Y-SAC64, 867571-0403 (also Logitech)		
525E83	Landel Mailbug LT301, Fcc:CNNMLA-27707-DT-E		
22D108	Lanix SK720P Fcc:GYUR59SK (also Liteon)(Euro)		
165B105	Lanpar Vision II		
831B103	Laser Pal 286(also Leading Technology) FCC: BNX84-H80-2269-1		
479B102	Laser 102 ("L" Shaped Enter Key)		
480B102	Laser XT (Rectangular Enter Key)		
354B90	Laser 128 EX		
35C101	Laser 386SX-T FCC: 1010DS (also Packard Bell,BSR,CMS,Leading Tech,Cordata,Leading Edge, Samsung,Emerson,Se Jin,Datatrain)		
109C102	Laser L386SX Slimline(also Expotech) FCC:IFS80-2269-1		
138D57	Laser PC5 Portable		
803B102	Latin America 102(Delta Tech)		
655A83	Leading Edge Model D DC2014		
15B101	Leading Edge D-2/D-3 Enhanced DC3014		
110C101	Leading Edge Model DC2214		
36C101	Leading Edge KB5191(also Chicony, Handok,Kris Tech,Auva)		
204C101	Leading Edge SMK 1030 (also Se Jin, Sherwood) DC3611		
35C101	Leading Edge CDC 2003 EAT1010 (also CMS, Leading Tech,Datatrain,BSR,Se Jin,Packard, Bell,Cordata Laser,Samsung,Emerson,)		
475C101	Leading Edge AK1012 FCC:JJEAK-1012S		
492C101	Leading Edge 5369 (also BTC)		
831B103	Leading Technology 5500/7000DX(also Laser)		
34C101	Leading Technology 5000/6800SX GJJ4AKEAT-1010R2(also Samsung,CSS,Se Jin)		
35C101	Leading Technology 6000SX Datatrain FCC: GJJ4AKEAT-1010DS(also CMS, Cordata,Laser,Samsung,BSR,Emerson) Leading Edge Se Jin,Packard Bell)		
312C102	Leading Technology PC PARTNER FCC: BNX84h80-2269-1		
329A85	Lear Siegler ADM#5		
503A84	Lear Siegler ADM#11 Pyramid Keys		
325C84	Lear Siegler ADM#11 full keys(also Zentec)		
836A107	Lear Siegler ADM#12(+)-ADM#11(+)		
251B122	Lear Siegler ADM#42		
918A87	Lee Data 87 Keys 343700102		
938A90	Lee Data 90 Keys		
214B122	Lee Data 122 Keys(also Harris,Memorex, Honeywell,Idea)		
515B124	Lee Data 2280		
513B122	Lexmark 901022-50 LX122US(also Lynk,IBM)		
628A101	Lexmark 1397651 Model M (also Dell, IBM)		
601C101	Lexmark 71G6120 FCC:IYL1398418		
513C84	Lexmark 1397901 Mini model M4 (also IBM)		
672C109	Lexmark 139907 w/trackball FCC:IYL1398150 (also IBM)		
483A101	Liberty Freedom 100		
351A103	Liberty Freedom 110		
153B107	Liberty DG		
186B101	Liberty 101 Enhanced #116406		
78C101	Liberty 116545-001(also Hitek)		
949A103	Link 125		
16B84	Link P.C. Term		
17B84	Link Alloy PC		

P/N	Description	P/N	Description
692B102	Link MC2/MC5 3 lights EPC (also Alpha Micro) Wyse 84035830/50-120-000-102	70E107	Lite-On SK1500C, Rec enter
539B105	Link MC5(raised above F keys)	94E109	Lite-On SK1689, Fcc: GYUR89SK (Euro) "7" enter (also AIMC, Dell, Comapq)
579B105	Link MC5(flat above F keys)(also Wyse) ANSI 50-120-000-101 (also Unisys TO300 European)	196E120	Lite-On SK720-H (Euro), GYUR59SK, "7" enter key
840A101	Link MC5 ASCII P/N 50-120-000-100 (also Altos, Wyse)	545D105	Lite-On Sk7100, Fcc:GYURSK7100P (also PC Concepts)
511B102	Link 50-120-000-103 (also Radio Shack,Brother)	502E42	Lite-On SK7510 (also RTI)
118C105	Link MC27 105 Keys/220	980D104	Little Tykes Kybd. #1721, win keys "L" enter
119C113	Link MC27 113 Keys	499D89	Litton Data Systems "LKEY0010" "PVT1"
250C103	Link IEPC (Euro)p/n 50-120-000-104	735D104	Logitech M/N RT7R5XTW Fcc:DZL122799 Rec. Enter
352B105	Link MC-3-220 (also NEC)	435D121	Logitech SK2500, YSB-3, Fcc:GYUR40SK Multimedia (also PC Concepts)
618A105	Link 105 (also Wyse, Triad)	890D104	Logitech Sk-720,YSA2, 867061-0100 Deluxe 104, Fcc:GYUR49SK
27D108	Link 108 50-120-320-001	891D116	Logitech iTouch, Cordless, Y-RB6, RT-7R00,RT7R20, YSE-8,Y-BC9, YBA9 Fcc:DZ1201252, 1124254-101A, 867074-0100, 967018-0403,RT7R10, 867061, 867196 -0703, 867039-0100,867063-0100 Multi. (also Dell)
817D105	Link P/N 900244-67 (also Wyse, Triad)	897D117	Logitech iTouch Pro #YRB7, YRJ7,867039-0100, DZL211255 Ergo w/win Multimedia
244C101	Linksys 386 SX/25	110E107	Logitech Y-SG13, YRC14, RT7R01, 867090-0100, DZL221407, RT7R11V:58TW, Rec enter, Curve space bar, 3 keys above directionals
543D104	Linkworld Model 104DYW54-114 Fcc:J2S104DLY	26E107	Logitech YSF-11 (also Acekey)
516D105	LinkWorld Model#105DYW76-596,KB-6001 Fcc: J25104DLY	304E122	Logitech Y-RF21, Y-RE20,Y-RJ21 RT7R03V:5XTW, DZL211498, Cordless, Multimedia
660D104	Linkworld Model 104DAW15-19 Fcc:J2S104DAW	408E124	Logitech Y-BF38, RT7R26 V:58TW, Y-BE22, RT7R24, Y-RJ20, ERGO,ELITE, 967231-0403, 867223-0100 Multi, Rec enter
675D104	Linkworld Model 104DYW66-485 Fcc:J2S104DLY (also Unicomp)	424E123	Logitech Y-RF21, Y-RE20 Fcc: DZL211498, ERGO
861D104	Linkworld Model 104DAW24-100 Fcc:J2S104DAW, Rec enter	477E115	Logitech Y-RH35, Y-SR34, RT7R06.access duo 967305- 0403, 967225-0403, 967228-0703, 867221-0100, Fcc:JNZ128481
926D104	Linkworld Model 104DYW10-100 Fcc:J2S104DLY Rec enter	580E111	Logitech Y-ST39 Rec enter, Multimedia, Win.
349E108	Linkworld Win98, rounded keys, curve spacebar	585E107	Logitech Y-SR47 (also Labtec)
291B101	Lite-On 101 Enh SK8831/SK8821/SK8801B-IU SK8802R (also Computrend,Jade,KLH) FCC: GYURO55K	725E107	Logitech Y-SP32, ACK-270A, Curve spacebar, back-L enter (Also Acekey)
724C102	Lite-On SK8802R (EURO-UK)FCC:GYU30H-SK-8802H)	739E104	Logitech Y-SU45, 867378-0403, 867560, 967334-0403 rec enter
555C101	Lite-On SK-8801EN FCC:GYURO9SK	740E109	Logitech Y-RQ57, 867397-0403, 967407-0403, fcc:JNZ201774, Cordless Desktop Express
15C101	Lite-On SK-0002-1U	1600B105	Logitech Y-SD5, SK6201
286C101	Lite-On SK-8843-IU FCC:GYUSK-8843(also Alton)	1991B107	Logitech Y-SQ33, SK2910
445C101	Lite-On 4100R model Sk4100 RIU FCC:GYURO2SK(also Arche)	758E135	Logitech Y-RR54/LX-700, RT7R33 fcc: DZL131836M Multimedia, rec enter
579C101	Lite-On SK1000RS FCC:GYUR10SK Rectangular Enter Key (also Dell,AST)	759E127	Logitech Y-RQ53, LX-500, RT7R31, fcc:DZL131139 Multimedia, rec enter
565C101	Lite-On SK2000R FCC:GYUR10SK "L"Enter (also Zenith,Ultra,Elite, Hewitt Rand)	769E119	Logitech Y-RQ52, LX-300, RT7R14, Y-BH52, 967234-0703 867395-0100, 867401-0100, RT732,967415-0403 DZL131836
753C101	Lite-On SK-3000R FCC:GYUR09SK(no pencil Bar) (also Silitek)	783E103	Logitech Y-SU61, 867462-0403, rec enter
936C101	Lite-On SK-1200 #230851-001C(Also AST,Hitek) FCC:GYUR15SK	822E128	Logitech Y-RR53 (Euro), RT7R31, Fcc:DZL131838 A7"
970C104	Lite-On SK-1100CW w/window keys "L"enter FCC:GYUR26SK (also PC Concepts)	861E113	Logitech Y-RK56A (Euro)
579D105	Lite-On SK1100CW (Euro) W/Win	864E104	Logitech Y-SAC64, 867571-0403 (also Labtec)
09D104	Lite-On SK1000REW/SK2000REW w/windows Keys FCC: GYUR26SK (also Dell)	870E115	Logitech RU58, 867400-0403, Fcc: 03L-PT03-K2F
48D108	Lite-On SK6000 (also PC Concepts) FCC:GYUR33SK	877E115	Logitech EX110, Y-RR71, SK7207
957C104	Lite-On RT6655TW FCC:AQ6MTN7Z15(also AST,Hitek)	895E114	Logitech Y-RK49, 867318-0403, Fcc: JNZ201587
285D104	Lite-On SK2000REW-KK2003WRIU w/win keys FCC: GYUR34SK "L" shaped enter	892E135	Logitech Y-YRAM74, 867616-0100 Fcc:DZL134041
391D116	Lite-On SK2501 FCC:GYUR38SK Multimedia (Also Hewlett Packard)	917E123	Logitech MX5000, Y-RAH72, RT7RB1, 867615-0403 DZL201974
435D121	Lite-On SK-2500 FCC:GYUR40SK Multimedia (also PC Concepts)	918E96	Logitech Dinovo Y-RW42, 867431-0100 Fcc: DZL201801
621D122	Lite-On Sk-2500 (Euro) Fcc:GYUR40SK (also PC Concepts)	923E111	Logitech Y-SZ49, 867449-0403, Rec Enter
692D101	Lite-On SK710 Fcc:GYUR12SK (also ATR)	196D101	LT-5000 AUS-101 FCC:JNPLTK-8049-5M
498D104	Lite-On SK710W Fcc:GYUR29SK W/Win	338D101	LT-6800 FCC:JNPLT-6800
822D108	Lite-On SK720P Fcc:Gyur59sk(also Lanix)(Euro)	994B122	Lynk Lynklite III
694D104	Lite-on G9900 P/N 7001024 Fcc:GYUR51SK (also Gateway)	513B122	Lynk 901022-50 LX-122US (also IBM,Lexmark)
645D105	Lite-On G9900-2D (Euro) Fcc:GYUR61SK	16C102	Lynk 102
713D88	Lite-On SK7500 Website Keyboard Fcc:GYURSK7500	665D103	Lynk 90100500 (Euro)
202D104	Lite-On SK5002W	939C105	Macally MK105 FCC:12MACALLYMK105X
764D104	Lite-On Tucson 2000 (SK2001) Fcc:GYUR37SK Win Keys, Back L enter (also Maxiswitch)	899D105	Macally ikey Rec enter
986D108	Lite-On SK-1500 (Euro) Fcc: GYUR63SK 3 buttons on top, "7" enter	442B101	Magitronics D-K 172 FCC:FMA44HKB6251 (also NTC,Zeos,NanTan,BSC,Twinhead, Premier,Dataware,Wang)
388B101	Magnatronic 101	498C102	Magitronics DK-170/DK171-B FCC:IYNKPT-102
819B108	Magnatronics FK2000(+)(also Focus)	725B101	Magnatronics K158 (also Unitek)
		726B101	Magnatronics K159 (also Unitek)
		584B101	Magnavox/Headstart KKB5181(also Chicony,

P/N	Description	P/N	Description
	Hyundai,ARC,Identity)	684D90	Metrobook VL Laptop Fcc:A3LS590
454B91	MAI Basic IV model 4309	615C84	Microbilt MB3724 CC Reader FCC:GUM35B-19442-DT-N
01B91	MAI Basic IV/Model 4313 400646-001	202D104	Micro Innovations,multimedia SK-5002W FCC:GYUR30SK (also Liteon,Reveal)
947B110	MAI Basic IV DT4315-001(also Fujitsu)	108D104	Micro Innovations KB5911(also Chicony)
948B111	MAI BASIC IV DT4315-002	978D108	Micro Innovations KB1001R+, Ergo. "L" enter (also PC Concepts)
815B92	MAI Basic IV 400646-052	590E108	Micro Innovations KB200i, CH#91120374 Back-L enter Three keys above arrows
816B92	MAI Basic IV 400589-002 model 4312	876E117	Micro Innovations KB982W, Fcc: 10WRKM074XXX XXXXXXXX Micron ALL MODELS SEE HITEK
431C82	Marquardt 7065 FCC:IYZ7065	538C101	Micron RT6656(+) Fcc:AQ6-CYPRESS (also Hitek)
796C72	Marquette Electronics 401574-002	875D89	Micron (TREK R) NBKU375 Laptop W/win, Glidepoint
797C61	Marquette Electronics 411656-001	140E104	Micron #5121, FCC:E5XKBM104M10UC (also BTC)
648E110	Matias Corp. SMK-Power989, The Tactile Pro, Fcc: KM9-356M9ASMK	148E95	Micron N870-004CL6-M1-700, Rec enter, Glidepoint
851B101	Matrix 486/25 (SEE HITEK FOR OTHER MODELS)	652B101	Micronics PC4X(also Hitek,Arch Rival)
798B101	Maxar 101 589-002 (also Datatrain)	856B103	Micro Peritericos (Brazil)
316D84	Maxilan DX	501E86	Microslate Wireless FDC3402, Rec enter, (also Wombat)
792A84	Maxi-Switch AT (also Telex)2186002xx	739C104	Microsoft Natural #58221 M/N EO3786US FCC:CIGEO3786 (also Keytronics)
35B101	Maxi-Switch 101 Enh/ME101 218603XX/ 2189001XX/2189013("L"shaped Enter) 2191-0001-XX (also Everex,ALR,Gateway,Opus, Avtech,Easydata,Texas Microsystems)	98D105	Microsoft Natural (EURO) #58221 FCC:CIGEO3786 (also Keytronics)
689B101	Maxi-Switch 101 Enh. rectangular enter	529D104	Microsoft Natural "Elite" M/N EO6401PS2, KU0045 X08-76725
987B124	Maxiswitch "ANYKEY"(also Gateway) 2189014-XX	687D105	Microsoft Natural "Elite" (Euro) M/N EO6401PS2
953B102	Maxiswitch/PrintaForm (S.A.)	461D82	Microsoft "MININOTE" PORT MINI Laptop
221C101	Maxiswitch 218617(VFS#35B101 w/keyhole)	915D123	Microsoft Natural PRO M/N RT9401,RT9403,RT9402, 9431 MS# X01-94432 Ergo, Win keys, Rec enter, Multimedia
345C124	Maxiswitch Maxi-Pro II 2189022-00-211 FCC:D7J2189022-XX	916D114	Microsoft RT9410, RT9443, Internet, MS#X04-80803 X08-76763, X09-71487 Rec enter, Multimedia
406C105	Maxiswitch Portable 2186185-00-21	932D115	Microsoft Internet RT9410 (Euro), MS #X04-80845 Ergo, Multimedia, windows, "7" enter
566C101	Maxiswitch 2192004 FCC:D7J2192-004 (also CompuAdd)	12E123	Microsoft Internet Pro # Rt9420V:5FTW, MS#X04-86289 RT9421, RT9441, Rec enter, multimedia
148D123	Maxiswitch 2189037-00-003 (also NCD) Model N123NA	63E124	Microsoft RT9420 (Euro)
446D104	MaxiSwitch 2196002 Fcc:D7J2196001 (Gateway)	327E125	Microsoft RT9450, RT9461 win, multimedia, rec enter
537D105	MaxiSwitch (MagiPro) Euro Fcc:D7J2196-001	329E104	Microsoft KU8933, rec enter, (also Wyse)
540D104	MaxiSwitch "MAXISOUND" 2195012-00-001 W/ Windows and Speakers	448E119	Microsoft Wireless Multimedia 1.0A Keyboard, 1014, WBR0168, WUR0335, X09-66570, KB0168 C3KKB9, Rec enter key, X08-78035
764D104	MaxiSwitch Tucson 2000 (SK2001) Fcc:GYUR37SK Win keys, back-L enter (also LiteOn)	449E120	Microsoft KB0168 (Euro) Wireless multimedia
285C139	MCK-142 PRO 139keys only (also Ortek)	447E119	Microsoft RT-9470, ERGO, Wireless Optical
693B101	MCK-101 (also Oemax,Ortek)	663E106	Microsoft RT-9480, rec enter
360D89	Mega Image 911CD/ Samsung 911CD\Ocean PC FCC:A3LS500 w/ touchpad and win keys	742E128	Microsoft 1031 multimedia(22 Internet buttons)
42B100	MEI Keyboard (also Qume)	928E121	Microsoft 1031, KC0405 (15 internet buttons) X800152
628B102	Memorex/Telex 102 (European UK)	1988B102	Microsoft Optical Elite Desktop, 1011/1027 Fingerwheel left side (127 keys)
214B122	Memorex 1477 122RX43S-46E(also Honeywell, Lee Data,Idea,Harris)	805E124	Microsoft Wireless Comfort 1.0, 1008, 1027, 1029 x08-00015-001 Slide Rule left side
578B101	Memorex/Telex Freedom 1(European UK)	857E103	Microsoft RT2300, Wired Keyboard 500, X08-801382-002
308B122	Memorex 1196/1192	878E122	Microsoft Ergonomic 4000 Model 1048, KU0462
683B122	Memorex/Telex C/P#211292 (also Idea)	879E113	Microsoft Comfort Curve 2000, Model 1047, KU0459
450B101	Memorex/Telex 101 214114-006	904E120	Microsoft Remote Media Center Model 1044 X802485-002
757A87	Memorex 2178	778C105	Microspeed KB105M FCC:FUUADBKEY001
758A122	Memorex 2179	931C104	Microspeed KB295 SKR-2033 rect. enter 9724-M (also Sejin)
03C107	Memorex M-22(also,Honeywell,Bull)	401D89	Microspeed KB-086-P wireless w/trackball w/win keys FCC:GJJSWK-8695WT
164B83	Memorex 2051	643D89	Microspeed KB200 (also Sejin)
846A87	Memorex 87 Switch L97990451	102A67	MicroSwitch #12343
902A88	Memorex #96272125 (European UK)	10B101	MicroSwitch 101/Honeywell
903A88	Memorex #96272471 (European UK)	471B102	MicroSwitch 102(European)(also Victor)
506B87	Memorex Model 589584/2078	857B88	Microtech HF88 (Brazil)
282B122	Memorex 122 Switch	136B105	Microterm 4525
48C102	Memorex/Telex 211760-001	171B109	Microterm VT 100
121C104	Memorex/Telex 104RX33S C/P211761-001	170B105	Microterm 5510-VT220
151C101	Memorex/Telex 101RX33S-6E(also Dec, Honeywell)	18C103	Microterm 103 key
201C85	Memorex/Telex Port EO4006002US (also Keytronics)	969C85	Midwest Micro TS30CS FCC:11RTS30CS
231C101	Memorex-Telex 101 #961459-001 AQ659ZMT (also Compuadd,Hitek)	978B84	Miltope 84
653D105	Memorex TS1000 (also Belkin)	809D86	Mini Keyboard 5510M
810D108	Memorex TS1000 108 key (also Belkin)	947A102	Minta 286/386(5339) (also BTC, Packard Bell, Hyundai)
359E120	Memorex MX5200, multimedia, windows, rec enter	477B101	Mitac 101
641E104	Memorex MX5000, TS1500		
749A58	Memotech MTX 512		
603D88	Metrobook II Laptop w/touchpad		
727B101	Minta 286/386/486/P9(K-160/K-260) (also Unit Tech,Digicom)		

P/N	Description	P/N	Description
662B101	Mitac Colonret 1017/K65201	61E108	Monterey K-292 (Euro) Fcc:FKD46AK292
669C102	Mitac 5182 FCC:E8H51KKB-5182(also Chicony)	14E107	Monterey K-290 Fcc:FKD46AK290 (also AOPEN)
184C102	Mitac 5349(Euro)(also BTC, Pack Bell, Facit, Donatec)	279E107	Monterey KB-855 back-L enter (also AOPEN)
25E88	Mitac #6133, windows, glidepoint (notebook)	371E104	Monterey AK5300 Fcc: FKD46AK5300 (also Keytronics)
351B84	Mitek K2AX	599E107	Monterey K297, Fcc: FKD46AK297 (also AOPEN)
808B44	Mitel SX-2000	2037B107	Monterey K-293
185B101	Mitsubishi Enhanced 101	761B102	MOS VTS II Postal Keyboard
704B101	Mitsubishi 101+ MP-82KBA"L"shape return	627E90	Motion Computing KB-1011
338B101	Mitsubishi 030 MP-82KBA(also Keytronics, Datamaxx, AGI, Goldstar, Premier, Spear Technology, Gateway)	444A67	Motorola KDT 480
529B102	Mitsuma Mini(5339R)(also BTC, Goldstar Packard Bell, Tatung, KLH, Hewitt Rand)	620A86	Motorola Four Phase 7200
586B101	Mitsumi 101 (also Compuadd) KPQ-E99-YC	50B14	Motorola Hand Held
403B101	Mitsumi 101 KPQ-E99-YC (Rect. Enter)	97B91	Motorola FT 45/KP409
255C101	Mitsumi KPQ-E99AC FCC:EW4KPQ2479A "L" Shaped Enter Key"	646A105	Motorola AA220 (also Ampex)
656C102	Mitsumi KPQ-E99AC (EUROPEAN) 102 Keys	564C72	Motorola (MDI) 9100-386/9100T/9100WS
485C101	Mitsumi KKR-E99AC/KPQ-E99ZC-12 FCC:EW4KKR4018/CMYKPQ6640 "L" Enter Key	818B63	Motorola (MDI) 9100-10/9100-11/3013A
643C102	Mitsumi KKR-E99AC (EURO) 102 Keys	62C72	Motorola (MDI) 9100-20
542C82	Mitsumi 50921006 (also Epson)	197C14	Motorola 9100 series monitor numberpad
622C101	Mitsumi KPQ-E99AC (Rectangular Enter Key) (also Compaq, Hitek) 160648-101	384D81	Motorola Mobil Term.MW-520 w/glidepoint
12D104	Mitsumi KPQE99ZC-13/ KPQEA4ZA model ZW FCC:KPQ7461 w/window keys "L" enter FCC:CMYKPQ6987	173E84	Motorola BLT, Touchpad, Rec enter MW520 Backlit
538D104	Mitsumi KPQE99ZC-13 (rect. Enter Key)	175E82	Motorola BL82, Glidepoint, Rec enter
113D104	Mitsumi KPQEA4YA-15 w/windows keys FCC:CMYKPQ7067	224E10	Motorola CDM-4550-LS
131D105	Mitsumi KPQE99ZC-13(EURO) FCC:CMYKPQ6987	500E87	Motorola MW800, P/N 4080364L12, Glidepoint
314D104	Mitsumi KPQ-EA4AA-18 FCC: CMYKPQ-7103	745E84	Motorola /TG3 BLT, KBA-BLT
584D105	Mitsumi PCK104-SKB (Euro) Fcc:CMYKPQ7615	746E82	Motorola /TG3 BL82, KBA-BL82A
601D104	Mitsumi KFK-EA4XA Fcc:CMYKFK7741 Back-L enter	828E93	Motorola ML900 with Fingerprint
881D104	Mitsumi KFK-EA4XA Fcc:CMYKFK7741, Rec enter key	201D104	Mouse Systems KWD203 Fcc:Liakwd-200
982D105	Mitsumi KFK-EA5XA Fcc:CMYKFK7741, "7" enter	916E90	MPC Transport X3100 laptop
339E119	Mitsumi KFK-EB9HY Multimedia, back L enter	*****	ALL Mtek models SEE MONTEREY
515E105	Mitsumi KFKEA4SA (Euro), Fcc: CMYKFK7835 7" enter	798A98	Multitech 98 Switch
1886B087	Mitsumi KFKE87YY	961A97	Multitech KB 097AT(also Acer)
476C101	MKB-931 (Taiwan) FCC:KFJMKB931	73B101	Multitech KB101 (also Acer, Stone System, Delta Gold, Cannon, MultiTech, Texas Instrument, Data General)
280D104	MKB-951 w/win keys FCC:KFJMKB-951	442B101	NAN TAN KB6251EA(also Zeos, Magitronics, BSC, Twin Head, Premier, Dataware, NTC, Wang)
519D81	Mobil Data Systems Data 911	870B101	NAN TAN KB 6151EA (also NTC, Unitek)
818B63	Mobil Data Terminal 9100-10/9100-11/D3013A	710B97	NCD N-97
62C72	Mobil Data Terminal 9100-20	711B101	NCD 100 (Northern Telecom, Hitek)
519D81	Mobil Data Terminal MDS-2000	154C108	NCD-N108LK (also Hitek)
851B101	Model America 116626 (SEE HITEK FOR OTHER MODELS)	478C101	NCD N-101M 119063-001 (also AST, Hitek, NEC, Dec, Compaq)
34B105	Modgraph 105 Switch GX 2000	14D107	NCD-107
730B102	Monterey K104 (also Actebis, M Tek) FCC:FKF456K-104	148D123	NCD model N123NA(also Maxiswitch) 2189037-00-003
91C101	Monterey K104(101 key Version)	711B101	NCD N-101PS (also APC, HITEK)
92C101	Monterey K108 FCC:FKD45AK108 (also Celem)	611A95	NCR PC-4/PC-6
135C101	Monterey K208 FCC:FKD46AK208 (also Sunshine, Protouch)	726A116	NCR PC-8/916/Enhanced(also Honeywell)
140D104	Monterey K-208 w/windows keys	560B101	NCR 916/Cherry G81-3000 RS3000 G83-3077-SBU
283C81	Monterey KB-MINI-81K FCC:FKD46AK110P (also Suntouch, Protouch)	81B100	NCR 4940 (also Adds)
610C102	Monterey K-208 (EURO, S.A.)FCC:FKD46AK208	996A112	NCR 112 Switch
260D105	Monterey K-208 w/win (EURO)FCC:FKD46AK208	475A75	NCR 2830 Indust.Grade Term.(75 keys)
552D104	Monterey K-280 W/Win Fcc:FKD46AK280	476A82	NCR 2830 Indust.Grade Term.(82 Keys)
553D104	Monterey K-288 W/Win Fcc:FKD46AK288	129C105	NCR ANSI 117085-001(Also Hitek)
578D105	Monterey K-280 Euro Fcc:FKD46AK280 W/Win	295B101	NCR 2950/4940 Class K140
617D105	Monterey K-288 Euro Fcc:FKD46AK288 (also Keytronics)	584C84	NCR 3150 Model 0110 Laptop w/Trackball FCC:83LS39355SC
840D122	Monterey K-360 Fcc:FKD46AK360 With Win keys, multimedia keys, Back-L enter	516B101	NCR 101 Workstation 3299-K430
867D107	Monterey K-288 Fcc:FKD46AK288, Back-L enter, win keys, 3 extra keys over directional keys	843B108	NCR 7052
918D108	Monterey K-288 (Euro) same as above	500B98	NCR 7930
919D105	Monterey K-220 (Euro) Fcc:FKD46AK220	986B112	NCR 7070 VDU (P.O.S.)
921D108	Monterey K-289 (Euro) Fcc:FKD48AK288	70C106	NCR 3413-K440-V001(also Adds, Hitek)
73B101	NEC Powermate APC/286/286+ model HA410	608C83	NCR 2850
		827C109	NCR P.O.S. model 7450 F/K-100
		41E108	NCR 7452, P/N 497-0411737, C/C reader
		891E111	NCR 5932-51 497-0432900
		401A67	NEC 8201/8300 portable
		889A85	NEC Multi-speed portable PC 1601/1602/1602-2EL
		324B93	NEC Powermate Portable
		37B101	NEC Powermate III/III/APC 412 FCC:7ZAPCH412 , 410E (also Data General, Acer, Stone, Delta, Cannon, Multitech, Tex.Instr)
		93C98	NEC/Jalpas SO740-03KB

P/N	Description	P/N	Description
352B105	NEC Visalink 220 (also Link)	121E64	NTS Dreamwriter T100, T110, T400, T400/IR, IR
113C78	NEC Ultralite PC17-02 Portable	122E64	NTS Dreamwriter IT, Dreammax 700, Fcc:NFJC600
180C78	NEC Ultralite 286F PC-22-01 Portable	748A84	Oak Switch 84 Position
661C85	NEC Ultra Versa 50E 440-1531 laptop Model PC-450-1521 FCC:A3DP51S	121B105	Oak Switch VT 220 Style
478C101	NEC ready 433ES (also Compaq,Hitek, Dec,AST,NCD) #158-050550-000	431B98	Oak Switch 5-64951-049
658C102	NEC FE-100-S102 (EURO) 102 Keys	746C105	Oak 5-64995-195 (also Bell & Howell)
738C83	NEC Versa V/50 FCC:B7ZP7	360D89	Ocean PC 911CD/Mega Image 911CD/Samsung Portable Laptop FCC:A3LS500 w/touchpad
996C83	NEC Versa S/33 Portable laptop PC-120-412201 FCC:EF7PC130S1033	693B101	OEMMAX Mac 101 MCK-101(also MCK,Ortek)
106D88	NEC Versa 2000C PC-6010-11402MW FCC:EF7PC600601RT1	694B31	OEMMAX (Multi-key pad)31 keys
247D85	NEC Versa 4050H/6040X Laptop w/ glidepoint PC-6110-71602 A3DP8/A3DP55	626C32	OEMMAX (Multi-key pad)32 keys
916C104	NEC 5923 (also Chicony,Reveal,SIIG,IBM)	169C101	OKI HMB 35957-14
509D104	NEC KB8963 #158-052288-000 W/Win	170C101	OKI HMB 35957-70
591D80	NEC MobilePro 700 Minilaptop W/Win	410B95	Olivetti 3/ANK2465
593D80	NEC MobilePro 750 Minilaptop W/Win	399B87	Olivetti ETV3000/EVT 260
795D78	NEC Mobilepro 770 Fcc:BSTJPN-3352DTE	363B102	Olivetti M24/ANK 2462
796D78	NEC MobilePro 800, 880	364B99	Olivetti M40/M48/M64/Ank 1427
803D90	NEC Ready 220T Laptop W/Glidepoint, Win	610B102	Olivetti 240/280 (European)
507E78	NEC Mobilepro 900, Model MP9000	144C101	Olivetti ANK-27-101
545E78	NEC Mobilepro 900 Rounded Corners	454C102	Olivetti ANK-27-102N (Euro)
905E106	NEC PC9800 model 699526	750C101	Olivetti ANK-28-101
741D96	Netsurf Fcc:NFDSKM9701-T, Back-L glidepoint	888B60	OmniFax
814D105	Netier ACK210 Fcc:L2BACEKEY210 (also ACEKEY)	795B65	OmniNote
441D104	Nimble NBK2104-5/S Fcc:GOGAPC-21 curve spacebar	06C84	OmniNote Model 2100 new
254D105	Nimble FCC:MDTNBK-110X "L" enter	854E07	Omnitech 50.OMTKB.001
255D105	Nimble FCC:MDTNBK-110X "7" enter	768B106	Online (also Soroc)
860D109	Nimble NBK-2104-5/S, Fcc: GOGAPC-21, Win keys Back-L enter, Curve Spacebar (also APC)	88A93	Ontel 93 Switch Keyboard
909D109	Nimble SPK-2000 (F-21YQ) Fcc:GOGAPC-21 (also APC)	35B101	Opus 8140(also Maxiswith,Everex,ALR Gateway,EasyData,Texas Micro,Avtech)
193E125	Nimble F21GQ, Fcc:GOGAPC21 "7" enter, (also ACE, PC Concepts, Softkey)	626C32	Ortek MCK-32S Keypad Only FCC:GM8MCK22LT
544B121	Nixdorf Ct08 (European)	694B31	Ortek MCK-31S Keypad only 31 keys
545B126	Nixdorf Ct05 (European)	285C139	Ortek MCK142 PRO FCC:GM8MCK142PRO(also MCK)
729D105	NK-33 W/Win, Back-L enter, Curve Spacebar	310E143	Ortek MCK142 Pro Fcc:GM8MCK142PRO (143 keys)
730D104	NK-33 W/Win, Back-L enter, Curve Spacebar Universal shift keys	693B101	Ortek MCK-101(also MCK,Oemax)
930D109	NK-688 Fcc:NZHKN-33, windows, Curve Spacebar	552C101	Ortek MCK-101FX w/Template Compartment FCC:GM8MCK-101SX
1679B108	NK-558 ***** NMB Technologies -See Hitek *****	373C105	Ortek MCK-104 PRO FCC:GMB3ZT-MAK105 (also ETC, Power Glide)
565D104	NMB Tech. RT-8255CW+ W/ full spacebar	225D104	Ortek MCK701W w/win keys FCC:GM8MCK101M
232D105	NMB Technologies RT-8255CW+(also Hitek)	570D18	Ortek MCK 18 Keypad
599D108	NMB LK401 P/N 122530-001 (also Fisher Rosemount)	693D85	Ortek MCK84 Fcc:GM8MCK84PAD (also Suntouch)
478C101	NMB RT3555+ Fcc:AQ6MTN56Z15 (also Compaq, Dec)	685D104	Ortek MCK600W Fcc:KJXMCK701W (also PC Concepts)
168C127	Northern Telecom NT 4X81DA "TOPS MP"	546D106	Ortek TKB970
711B101	Northern Telecom Keyboard(also NCD,Hitek)	975D107	Ortek MCK701W, Fcc:KJXMCK701W, "L" enter, Curve spacebar
70B101	Northgate 101	68E122	Ortek MCK800 (also Truetouch)
237B101	Northgate Omni 102	366E86	Ortek MCK-84/MCK-86 Fcc: GM8MCK84KBPAD, A7" enter key
313B107	Northgate Omni 102 (+)	529E101	Ortek MCK-91 (also Adesso)
312B103	Northgate NEW 102	1888B107	Ortek MCK-2000 (also Kensinko)
564B119	Northgate Ultra	530A88	Osbourne Executive
13C116	Northgate Ultra-T	975B59	Osys (European)
618B108	Northgate Omnikey"N"101-N	41C34	Osys Mapec 03062 (European)
619B102	Northgate Omnikey"l"101-l	231B102	Packard Bell Enhanced
891B101	Northgate Omnikey 101-NI	438B101	Packard Bell FKB4700 (also Fujitsu,Data General, Dasher)
892B104	Northgate Omnikey KA102	529B102	Packard Bell Legend IV (also BTC, Goldstar,Mitsuma, Tatung,KLH,Hewitt Rand)
192C120	Northgate Omnikey Ultra-F	701B101	Packard Bell 101 Key
315D117	Northgate Omnikey Ultra-TP w/win keys FCC:GT6OMNIKEY	464B84	Packard Bell KCLEA907L
375C83	NP-92 Portable FCC:GS6NP-902S	427B101	Packard Bell Enh 101 (also BSR)
701E90	N spire model #CL50, rec enter, Glidepoint	947A102	Packard Bell 286(also BTC,Hyundai,Minta)
443B101	NTC KB6451EA (also Zeos,Nan Tan)	184C102	Packard Bell(EURO)(also BTC,Facit, Mitac,Donatec)
870B101	NTC KB6151EA (also Nan Tan,Unitek)	35C101	Packard Bell M1US06A-P9 FCC:KEAT1010DS also(Leading Technology,DataTrain,CMC BSR,SE Jin,Cordata,Laser,Samsung, Emerson Leading Edge)
442B101	NTC KB6251EA (also Zeos,Nan Tan,Magitronics, BSC, Twin Head,Premier,Dataware,Wang)	332C101	Packard Bell BPCS#120019 (Also BTC,Reveal) FCC: E5XKBM111
220C101	NTC KB 6351	710C101	Packard Bell 5130 BPCS #120032 FDA1021 (also BTC) FCC:E5X5R5BTC
402C101	NTC KB 6551 FCC:FMAKB6551(also Unitek)	647C102	Packard Bell 5149(EURO) 102 Keys(also BTC)
386C101	NTC FCC:ISNJ-168(also Sunshinne)	08D105	Packard Bell 5131C/SK2100W/FDA1051 (also BTC) FCC:E5XKBM10510/E5XKBM10610
120E64	NTS Dreamwriter 200, NTS C200 Fcc:NFJES250	512D116	Packard Bell FDA-116CA MULTIMEDIA Fcc:F4ZFDA116CA
833C85	Packard Bell Statesman(+) 810414 Type NTB003 FCC:DGI-H4805 (also Zenith)		

P/N	Description	P/N	Description
52E117	Packard Bell FDA-116CA (Euro)	942B122	Pendar 122K (European)
119E07	Palm Pilot Ille (also 3Com)	44E122	Perfect Choice PC-200024, Multimedia
286E07	Palm Pilot Visor	438E123	Perfect Choice PC-200055, Multimedia (also APC)
602A83	Panasonic Senior Partner Portable	439E125	Perfect Choice PC-200048, (also APC)
878B77	Panasonic Portable KXD4925	85C114	Pericom MG-200-058(European)
982B84	Panasonic Business Partner 150 Port. (also Tandy 1110 Portable,Grid 1720)	187A64	Perkin Elmer 550B
253C85	Panasonic CF170 Portable	465A130	Perkin Elmer 7500
332B101	Panasonic 8899183-AU(also Radio Shack,Dec)	962A102	Philips 102 Switch
25D84	Panasonic CF-41 Laptop w/trackball	646A105	Philips TA35588(also Ampex 220)
453D89	Panasonic CF-25 w/touchpad/WIn Fcc:ACJ9TGCF-25	539B105	Philips P-2707(European)(also Link)
474D89	Panasonic CF-62 Fcc:CF-62EXE4AAM W/Glidepad	869B99	Philips P2855 (European)
558D89	Panasonic CF-35 W/ touchpad	851B101	Philips 117532 RT101+(2813-015) (SEE HITEK FOR OTHER MODELS)
622D90	Panasonic CF-45 Fcc:ACJ9TGCF45	943A101	Philips 2814 (EO3370)(also Keytronics,Radio Shack,AT&T)
626D84	Panasonic CF-M31 MiniLaptop	230C102	Philips P2814-043 (European)
711D89	Panasonic CF-71 Laptop	10B101	Philips P2814-000 Fcc:GJK35U101WN-2
712D89	Panasonic CF-27 Laptop	183E88	Phillips Web-TV KW1133/00F-US
914D90	Panasonic CF-47 Laptop W/Win, Glidepoint	373E101	Philips M3180-40010 (also Compaq)
571D91	Panasonic "LET'S Note" AL-N4 MiniLaptop Fcc:AL-N4T512J5 W/ Trackball	374E102	Philips M3180-40011 (French) (also Compaq)
22E89	Panasonic CF17/CF-M34 Laptop W/Win, Glidepoint	375E106	Philips M3180-40012 (Japanese) (also Compaq)
27E89	Panasonic CF37 Toughbook Fcc:4X2USA-33859-MM-E Windows, Glidepoint	730E109	Philips M3180-40015 (Japanese) (also HP)
169E90	Panasonic CF-48, Glidepoint, Rec enter	731E105	Philips M3180-40014 (German) (also HP)
362E89	Panasonic CF-72 Glidepoint, rec enter, windows	748E106	Philips KB-0316 (Korean) (also HP)
394E87	Panasonic CF-28, CF-29, CF-38,Rec enter	813C137	Pioneer P.O.S. w/cc reader model KB137-2
921E90	Panasonic CF-29 Full Seel	814B109	Pitney Bowes F192011(also Keytronics)
493E90	Panasonic CF-50 Toughbook	904C101	Planar INS-1180
576E90	Panasonic CF-73 Glidepoint	106C126	Pitney Bowes J684000/EO3556054 (also Keytronics)
670E90	Panasonic CF-VKBL01 (PDRC keyboard)	595B101	P.O.C. Echo 386
674E87	Panasonic CF-T2 Fcc:ACJ9TGCF-T21	282E107	Posiflex KB-3100 Series, C/C reader
756E90	Panasonic CF-51 glidepoint	655E125	Posiflex PST7000/6000/1000
1954B082	Panasonic CF-18	502C103	Positron model 912112-1
888E85	Panasonic CF-T4, Fcc: ACJ9TGCE-T41	628D105	Positron (Express) #912112-7 W/Win Keys
571A107	Paramax (also Intecolor)	359D105	Power Computing 55118
397C101	PC Accessories Model KB20030 w/Trackball Fcc: E8HKB-5581A (also Chicony)	373C105	Power Glide 105 FCC:GMB3ZT-MAK-105 (also ETC,Ortek)
443D104	PC Accessories P20035 Fcc:F2QKT95104	398C104	Powersource Computer Sys Keycat II Trackball FCC:HMN-2YZ Keycat
776C102	PC Concepts Model 7001 Ergo Keyboard Fcc:LIAKB-7000 (also Ace,Addison,Chicony)	424C101	Precision Instruments KB101RM Fcc:E8HKB5311
970C104	PC Concepts SK1100 CW w/windows keys "L" enter Fcc:GYUR26SK (also Lite-On)	653D105	Precision KB6868
48D108	PC Concepts "WAVE" ERGO w/window keys and Wrist rest,Model SK6000(also Lite-On, Reveal)	997D109	Precision KB6868,P/N F8E206, back-L enter 3 keys above directionals
357D109	PC Concepts SK6000 (Euro)ERGO Fcc:GYUR33SK	187B113	Preh Commander P.C.
225D104	PC Concepts #61596 Model SK701W	446B114	Preh Commander PC-AT3
282D106	PC Concepts Mac Wave Ergo 61500(EZ-9000) US version FCC:MWIEZ-9000	623B103	Preh Commander PC-19R
309D101	PC Concepts Standard 101 model F-21 Fcc: GOGAPC-21 (also APC)	971B79	Preh Commander M84AN/90307-007(Euro)
298D105	PC Concepts Turbo-plus w/window keys Fcc:HQB-BITS6001 #61590(also HQK)	495C86	Preh MF87 Keyboard 90300-085/0006AT
435D121	PC Concepts Quantum 2000 Multimedia SK2500 Fcc:GYUR40SK(Also Liteon)	629A101	Preh 101-CD102EX
201D104	PC Concepts KWD203 Fcc:LIAKWD-200, #61595	397D00	Preh 90318-000 MC80
545D105	PC Concepts "SURFBOARD" Wireless SK7100 W/Win., Multimedia Fcc: GYUSK7100P	398D63	Preh 90320-000 MC80 Alpha MC1WX
546D106	PC Concepts "EZBOARD" W/ Glidepoint #62970	362D00	Preh 90319-000 MC128
547D109	PC Concepts "WAVE2000 Convertible) SK6100W W/ Trackball Fcc:GYUR24SK	396D111	Preh 90320-200 MC128 Alpha
621D122	PC Concepts SK2500 (euro) Fcc:GYUR40SK (also Liteon)	02D77	Preh 90313-000 PC-POS
685D104	PC Concepts MCK600W Fcc:KJXMCK701W (also Ortek, KDS)	399D111	Preh 90314-000 PC-POS JR.
975D107	PC Concepts #6159698, Fcc:KJXMCK701W, "L" enter Windows, Curve Spacebar	400D28	Preh MC35 Keypad
976D107	PC Concepts #6184098, M/N KWD820, "L" enter	417C01	Preh M84W Universal
977D104	PC Concepts #63142 M/N KUB835, Rec enter,	510C84	Preh M84WX
978D108	PC Concepts #6151398, Turbo Stream, KB1001R+ Ergo, windows, "L" enter, (also Micro Innovations)	605C114	Preh M128WX
193E125	PC Concepts F21GQ(Euro) (also Ace, Nimble, Softkey)	750D128	Preh WX128
299E104	PC Concepts KWD-701, back-L enter (also Genius)	554D104	Preh M128WX 90402-011
538B102	Peacock 102 (European)	292A67	Preh AK87
594D119	Preh Commander PC-POS 90313-001/000 W/ Credit Card Reader	776E09	Preh MC128WXWANISLMI #90320-200-0000
		777E111	Preh MC128WX #90319-000-0000
		982A20	Preh NK20 (4 X 5)
		291B101	Preh Series 2000 Enhanced
		524C00	Preh M128WX Universal
		551B40	Preh 8 X 5 keypad
		767C44	Preh M84WX Special Configuration
		759C20	Preh 4 X 5 Keypad
		892C16	Preh 4 X 4 keypad
		767D25	Preh MC25 W/ LCD #90321-001
		05E110	Preh MC128WX, #90320-201-0000, CC Reader, Rec enter
		158E125	Preh MC128WX WN#90319-000 (all keys formed)

P/N	Description	P/N	Description
159E84	Preh MC84WXWNM1 90325-003		Multimedia, trackball, rec enter
221E117	Preh MC128WX, #90319-052/0000	249E108	Qtronix KB-985P (Euro), Fcc:F2Q4NE98A
235E39	Preh MC84WX S N M3 #90325-013/0000	401E107	Qtronix Scorpius KII rec enter
280E110	Preh MC128WX #90319-000/0000	241E108	Qtronix Scorpius KII+ (Euro), A7" enter
398E126	Preh MC147WX, #90320-601/5555 win, rec enter	404E107	Qtronix Scorpius KII+, Rec enter, Win Keys
399E106	Preh MF112C, #90320-411/0000 A7" enter	208B84	Quantel 52301 (84 Switch)
400E140	Preh MC140WX #90327-000/0000	638C68	Qualcomm Mobil Computer Model CV90-3656-1 PCIM6014
503E50	Preh MC80, WXWNSLK5, 90318-044/0000	382D70	Qualcomm Omnitracs #10-8575-21
589E49	Preh M84WX C1n01 90311-005/1001	699C69	Qualcomm Omnitracs 2000
676E80	Preh MC80WX 90318-000/0000 all keys formed	713E68	Qualcomm Omnitracs CV90-53152-4
919E68	Preh Commander	868E80	Qualcomm MVPE computer
338B101	Premier101 EO3435(also Keytronics,AGI, Gateway, Mitsubishi,Datamaxx,Goldstar,Spear)	916C104	Quantex KBD Win95 (also Chicony)
442B101	Premier250 KB6251 (also NTC,Nan Tan,Wang, Zeos,BSC,TwinHead,Dataware,Magitronics)	457E85	Quickpad IR, Wireless Keyboard
546D105	Primekey TB640 EG95PK (also PC Concepts)	458E85	Quickpad PRO
272B110	Prime PT 250K	456A85	Qume 101/102A QVT101 301453-01
353C103	Prime EPC-UK (also Qume)	587A91	Qume 103
953B102	Printaform AT/Maxiswitch (S.A.)	778A103	Qume 108
955B84	Printaform XT/BTC (S.A.)	566A102	Qume 109/119
783C101	Professional Key-Board TK-M501C FCC:IZITK-105M	927A102	Qume 109(+)/119(+)/101(+)
69E126	Professional P/N154758, Fcc:IZITK105M (Also Truetouch)	588A107	Qume 202
268E109	Professional PS2-3421, Fcc: IZITK-105M	554B105	Qume 203(+)/323EV
415E124	Professional Y-SN28, Fcc: IZITK-105M, A7" enter Multimedia, (also Labtec)	80C101	Qume QVT31
619E109	Professional KB-AK2002R, Fcc: IZITK-105M (also Alaska)	208C102	Qume 303496-04(Euro)
712E125	Professional multimedia fcc: IZITK-105M	257C105	Qume ANSI 363498-11
915E105	Professional KWD-701 (Euro) A7" enter (also Solidus)	42B100	Qume 303908-11 POS QVT-191 (also MEI)
790E107	Professional P010 Fcc: IZITK105M (also BenQ)	353C103	Qume QVT82 (Euro) (also Prime)
859B103	Prologica SP-16 (Brazil)	380C102	Qume QVT82 (US)/P/N 303688-11
817B101	Proteus 2001(also Focus,CSR)	807C101	Qume 303687-11
135C101	Protouch KB101PT(also Monterey,Mtek, Sunshine)	965C105	Qume 303686-11 "7" enter key
923B142	Provue Desktop/Fisher	955C101	Qume 303496-01
187C142	Provue Console/Fisher	89A67	Radio Shack TRS-80 Model III/IV
259C91	Provox,Fisher Micro desktop CPN11B8000X042(also Keytronics)	379A72	Radio Shack 100 Portable
80B36	Psion Organizer II	674A72	Radio Shack 102 Portable
634C56	Psion HC100 Hand Held Computer	650B57	Radio Shack Color III
621E58	Psion Notebook Pro 3100	385A101	Radio Shack Data Term.100(also Wyse,Altos)
705B101	Qtronics 301	649A90	Radio Shack Tandy 1000/2000 EX/SX
680B101	Qtronics 30BP with Ball Control	429B76	Radio Shack Tandy 1400 Portable
213C94	Qtronix KT-30/QX301(double Keys on Numeric Pad)	654A94	Radio Shack Tandy 3000(also Fujitsu)
799C101	Qtronix QX-301(EURO) FCC:F2Q4NEKT-30	943A101	Radio Shack 1000/3000 Enh. (also Keytronics,AT&T,Phillips)
839B32	Qtronix Mighty Keypad	890A82	Radio Shack TRS-80 Model 16B
311D18	Qtronix 18 key keypad QX-018	332B101	Radio Shack Tandy 1000SL(also Panasonic, Dec) FCC: AAQ99R25-4032
599C101	Qtronix QX-601R-AT FCC:F2Q-QX601	982B84	Radio Shack/Tandy 1110 Portable (also Panasonic portable 150)
726C102	Qtronix X681R (Euro-UK)	983B62	Radio Shack/Tandy WP-2 Portable
727C83	Qtronix Scorpius 83 Model QX883R FCC:F2Q-QX-883	254C101	Radio Shack 2500SX/25 (also SeJin,AST,Samsung,Trigem)
736C98	Qtronix KT-60Mw/trackball FCC:F2Q-KT60 (also Reveal)	511B102	Radio Shack/Tandy DT110 (also Link)
754C22	Qtronix numeric pad QX-022 FCC:F2Q-022P	903B115	Ramtek (115 Keys)
187D101	Qtronix QX-101 FCC:F2Q-QX101	589B91	Randon Colleague Portable
236D102	Qtronix-Scorpius 901(compact)F2Q-QX901L	993A86	RCA 86 Switch
402D105	Qtronix Scorpius 95 model KT95M FCC:F2QKT95104 w/Trackball & win keys	941B101	Recortec 7101N(also CSK)
422D104	Qtronix KT305 Scorpius FCC:F2Q4NERT-35	964B140	Reuters/Rich AK123KT (European)
423D108	Qtronix Scorpius 35 FCC:F2Q4NERT35W W/ Trackball	865C101	Reveal KB100 FCC:BTC55SERIES(also BTC)
443D104	Qtronix (Scorpius 104) Scorp104 Fcc:F2QKT95104	332C101	Reveal KB101 (also BTC, Packard Bell)
655D105	Qtronix Scorpius (Euro) Fcc:F2QKT95104	736C98	Reveal KB500 Trackball Kybrd FCC:F2Q-KT60 (also Qtronix)
691D32	Qtronix Mighty Keypad Scrprius32 QX032H	916C104	Reveal KB5923/KB195 (also Chicony,SIIG) w/window keys FCC:E8HKB-5323
759D124	Qtronix Scorpius 98N plus, Fcc:F2Q4NE98 Multimedia, Win Keys, Back-L enter	776C102	Reveal KB600 Ergonomic
952D107	Qtronix Scorpius 98A, Fcc:F2Q4NE98A,Scorpius 980A Plus, Fcc: F2QNE980 Win,Rec enter	48D108	Reveal KB695 (also Lite-On, PC Concepts)
197E107	Qtronix Scorpius 2KP/2KU/2KH, Rec enter	202D104	Reveal KB395 SK5002W (also Liteon, Micro Innovations) FCC:GYUR30SK
222E110	Qtronix Scorpius990P, Multimedia, rec enter	802A101	Rita 2010/E03417 (also Keytronics, AT&T,Arnet,Dell,Samsung,US101)
239E124	Qtronix Scorpius 980T Plus, Fcc:F2Q4NE980,	712A54	Rockwell Collins Aim 65
426C101	Samsung SEM-K20N-1, SEM-K20S (also Datatrain) FCC:E2XSEM-K20N, 20S	502E42	RTI SK7510 (also Lite-on)
		511D94	Sage Microsystems AUTOMOTIVE Keyboard
		35E91	Sager 3300C, Fcc:L4PK3100CX13, Rec enter
		740A106	Samsung 106 Switch
		802A101	Samsung Novell (also Keytronics, Arnet,AT&T,Dell,Rita,US101)
		129B101	Samsung KKB-5161 (Chicony)

P/N	Description	P/N	Description
35C101	Samsung 101 FCC:1010DS (also Packard Bell,BSR,CMS,Leading Tech,Leading Edge,Cordata,Laser,Emerson,Se Jin)	667B97	Siemens PC 16/32(European)
34C101	Samsung 101 FCC: 1010R2 (also Leading Technologies,CSS,Se Jin)	702B102	Siemens PC 32/20(European)
336C101	Samsung 1010SI FCC:GJJ4AKEAT-1010SI (also Se Jin)	854B126	Siemens MTS 2000 (European)
254C101	Samsung SKR-1032(also Radio Shack,Sejin)	855B123	Siemens Coros 2000 (European)
584C84	Samsung Sens 700 Laptop	985B127	Siemens 282D-K90-V320 (Euro)
360D89	Samsung SENS 500/Mega Image 911CD/OceanPC 911CD Portable Laptop FCC:A3LS500 w/touchpad & win keys	968B126	Siemens 232D-K320-P320 (Euro)
533D90	Samsung SENS Pro 520 Laptop Fcc:A3LS520	402E104	Siemens KBPC S EU, Fcc:SS01TASTK252, Rec enter
585D104	Samsung SEM-DC8H Fcc:E2XSEM-DC8H (Acer)	61C126	Siemens-Nixdorf SINIX G80-2507HAD (European)(also Cherry)
708D104	Samsung SEM-DT45/DT35 Fcc:E2XSEMDT45	381C119	Siemens-Nixdorf POS computer w/CC reader
95E105	Samsung SEM DT-35 (Euro), "7" enter	985C102	Siemens Nixdorf MF2-LC S-26381-K252-V120 (EUROPEAN)
323E104	Samsung SEM-C19V2 (also Systemax)	110D105	Siemens-Nixdorf KBPC-P-NOR/S26381-K210-V145 w/windows keys (EUROPEAN)
898E91	Samsung X25 Laptop M/N NP25C0003/CHN, Fcc: 6CTTAI-36146-M5-E	624D115	Siemens-Nixdorf POS (Euro)
441B101	Sanyo MSC0990(European)	791D118	Siemens-Nixdorf POS W/ CC Reader CRTA5702
438B101	Sanyo Multimedia FKB4700 (also Dasher,Data Gen,Fujitsu, Earthstation,Emerson,Vendex,Tatung)	623E73	Sigmation III
148C127	SASI P.O.S. KB1028	742C102	SIIG KB-M102 model 1914 Fcc:J6GKTIC-KBM102 KB-1922, cooltouch kids, Fcc:J6G-KTIC-KB-M102
554E93	SASI EX-10KB Cash Register Keyboard	916C104	SIIG KB1927 w/window keys (also Reveal,Chicony)
255B53	Satec 53 Switch	283C81	SIIG Minitouch KB1903- FKD46AK110P(also Monterey, Sun)
809B86	Scantech 86 Key	22D105	SIIG Truetouch fo MAC FCC:KJXB205
907E120	Scorpius P21 (also Keys U See)	457C101	SIIG Supertouch FCC:FK3459SKB101K (also Suntouch)
34C101	SeJin GJJeat-1010R2 (CSS,Samsung, Leading Technology)	609C101	SIIG Wavetouch 101KB JK0012 (also Acer)
35C101	SeJin GJJeat-1010DS(also,Leading Edge, Datatrain,Cordata,Laser,BSR,Packard Bell,Emerson,CMS,Leading Technology)	910C105	SIIG SMK105/Mac105KBGB JKML0011 FCC:KM9-3S6M9ASMK105
336C101	SeJin 1010SI FCC:GJJ4AKEAT-1010SI (also Samsung)	921C100	SIIG Supertrak(+) model JKAPE012 FCC:GM8MCK106TB
204C101	SeJin SMK 1030 (also Leading Edge,Sherwood)	922C110	SIIG Mactouch(+) model JK-MR-0012 FCC:SIIGSKB200MP
254C101	SeJin SKR-1032 (also Tandy,AST,Samsung, Trigem) FCC:GJJSKR1032B	923C106	SIIG Supertouch(+) model JK-AND-012 FCC:GM8MCK106TB
692C102	SeJin SKR-1032B-GEA (EURO)	453E91	SIIG KB1941 (also BTC)
931C104	Sejin SKR-2033 w/windows FCC:GJJSKR-2033 (also Microspeed)	753C101	Sillitek SK3000R FCC:GYUR09SK (also Liteon)
78D101	Sejin SKR-1033 FCC: GJJSKR-1032ZP4	861B70	Sisco Terminals (Brazil)
16D86	Sejin SPR-8630 Mini "J" mouse GJJSKR-8630	529E109	Skylink KB122
195D101	SeJin SKR1032BP FCC:GJJSKR1032BP	851B101	Smart And FRIendly386/40 (SEE HITEK FOR OTHER MODELS)
346D105	SeJin SK2233 w/win (Euro) FCC:GJJSKR2233	1915B103	Smart EZ-8000
931C104	SeJin SK2233 w/win FCC:GJJSKR2233	516C101	Smith Corona 6311-KE(also Acer 6311-W)
429D86	SeJin Mindpath SWK-8630 FCC:GJJSWK-8630 Wireless w/windows keys	938B101	SMK 101 (also Azuka)
432D101	SeJin SKM-1040 LEFT HANDED KEYBOARD FCC:GJJSKM-1040	182C111	Sodick 111 Key
618D101	Sejin EAT1010P2 Fcc:GJEAT1010BR (also Telmex)	229D105	Softkey GOGAPC-21 F-21-J
643D89	SeJin SPR-8697/W6 Wireless (Euro) (also Wombat)	756D105	Softkey F-21J(X) Fcc:GOGAPC-21 L-enter
757D101	Sejin EAT1010 Fcc:GJJSKM-1030BS Back-L enter	792D109	Softkey F21XQ Fcc:GOGAPC-F-21
926D104	Sejin 104DYW10-100 Fcc:J2S104DLY (also Linkworld)	915E105	Solidus Peripherals KWD701 (Euro), A7" enter
250E89	Sejin SWK-8650WT, P/N SPR5096WT6A, win, trackball	1961B108	Solitek PSK-5000H
620E86	Sejin SWK-8650W, SPR5096WS6A, Liberator II rec enter with windows	248D104	Sony KB7923 FCC:E8HKB5923 (also Chicony)
656E89	Sejin SWK-8695WT, trackball, windows, rec enter	16D86	Sony 8630 WEB-TV
671E89	Sejin SWK-3000WT, Trackball cutout, Curve Spacebar	206E86	Sony PCG-531A Laptop, Fcc:AK8JPN-35452-M5-E
657E89	Sejin SWK-8695WS, rec enter, pointing button	391E107	Sony PCVA-KB1P/MA, PCVA KB1P/UB Multimedia, windows, rec enter
771E104	Sejin SK-1788 rec enter, windows. (also Compaq)	390E108	Sony PCVA-KB1P/MA (Euro) multimedia, A7" enter win
256D101	SG-1000 FCC:KUG-SG-1000	654E108	Sony PCVA-KB4 P/U (Euro) A7" enter
476D107	SG-1000 Fcc:KUG-SG-1000 (EURO)	635E89	Sony Vaio PCG-9J4L, rec enter
446C77	Sharp PC-3000 Portable	744E108	Sony Vaio PCVA-KB4P/U rec enter
83E63	Sharp (Handheld PC) Monilon Tripad PV-6000, Fcc: VADCHN-40029-FB-E	2004B104	Sony Vaio PCVA-KB7P/U
792B105	Sherwood ANSI	288A76	Sorex 530
811B102	Sherwood EPC (102 Keys)	480A96	Soroc 550
204C101	Sherwood EPC P/N KS-EPC-RD (also Sejin,leading edge)	850A106	Soroc Elite 550
887B103	Sherwood I-EPC	768B106	Soroc Plus One (also Online)
812B101	Sherwood ASC II	338B101	Spear Technologies EO3435 (also Keytronics,AGI,Datamaxx,Goldstar, Mitsubishi,Premier,Gateway)
313C101	SR-8151B FCC:FPWSR-8151B(also Kurt Check)	617A84	Sperry PC
03D101	SR-7151B rect enter FCC:J75SR-7151B	405B101	Sperry 101 Enhanced
		892A95	Sperry Univac
		945A113	Sperry UTS 400
		631A105	Sperry 1220/IPC
		537A99	Sperry F4862 (also Keytronics)
		518C101	SR-9151-B / JKB-6151-B FCC:FPWSR-9151B
		73B101	Stone Systems (also Acer, Stone, Delta,Cannon,, NEC, Multitech) Texas Instrument,Data General)
		692B102	Stratus MC5 (also Link,Wyse,Alpha Micro)

P/N	Description	P/N	Description
232B84	Suntouch 84 Switch	575A111	Televideo 905/955
282C84	Suntouch JR.SIIG model K84JR FCC: GM8CK-84KBPAD	570A111	Televideo 921 (also AMPEX)
283C81	Suntouch JR.SIIG model KB-MINI-81K FCC: 46AK110P(also Monterey,Mtek)	538A125	Televideo 922
457C101	Suntouch SIIG Model K101 FCC:FK3459SKb101K	86A101	Televideo 924/925/950
693D85	Suntouch MCK84 Fcc:GM8MCK84PAD (also Ortek)	751B110	Televideo 935
215B95	Sun Keyboard 95 Switch	87B113	Televideo 9220
555B107	Sun 4	881A84	Televideo Telcat
337C118	Sun model type 5 N860-8701-T001-03A (also Fujitsu)	668B109	Televideo 965ASCII
370C119	Sun model type 5 N860-8701-T010-02A (also Fujitsu)	629B108	Televideo 965 ANSI/VT220 9320(also Wyse)
810C119	Sun Model type 5C N860-8703-T010 FCC:C9SKB8703 (also Fujitsu)	994A101	Televideo KB200 FCC:AQ659ZRT-101A 115034 (also Hitek,Wells,Earthstation)
911C118	Sun N860-8703-T001-03A	630B102	Televideo 965 Enhanced PC
953C102	Sun model EO3616US FCC:EO3713	142C110	Televideo 965 ASCII NEW
212D119	Sun Model type 5C,Class B FCC:C9SKB8703	242D110	Televideo 110 Key
894D119	Sun Type 6 M/N N860-8705-T010-02A	222D110	Televideo (Dec style) 110 key "7" enter
699E118	Sun Type 6, N860-8706-T401/10, rec enter	308B122	Telex 191/1192 (also Memorex)
135C101	Sunshine KMB-101 FCC:FKD46AK208 (also Monterey)	907B88	Telex Cat 1191D
386C101	Sunshine FCC:ISNJ-168(also NTC)	504B122	Telex 179
359D105	SuperMac ACK-310 w/win FCC:L2BACK310	837A88	Telex 078/079/080/1191/4108
648C102	Systemax SE9000 (also Dell) (EUROPEAN)	343B88	Telex 88 Switch
45E81	Systemax SW14-500C Laptop, M/N N30W (also Dell)	188B88	Telex FC 501
152E121	Systemax KB-9885, Multimedia, Rec enter (also Chicony)	792A84	Telex 84 Switch (also Maxiswitch)
323E104	Systemax SEM-C19V2, Fcc: E2XSEM-C19V2, back L enter	579E64	Telxon #21987-000
788E104	Systemax Standard	555A88	Texas Instrument PC Professional
119E07	3Com Palm Pilot III (also Palm)	163A60	Texas Instrument 743 KSR Printer
528E47	3Com #1102, P/N 655-0008-03	441A84	Texas Instrument 820 KSR Printer
278A92	Tab Products 92 Switch	90A88	Texas Instrument 911
788A84	Tab Products 84 Switch (692-0132)	669B55	Texas Instrument 700/1200 BPS Printer
648B105	Taiwan Clone VT-105	225A88	Texas Instrument 913
636C80	Tanac Keyboard Computer	754A103	Texas Instrument 924
230B84	Tandata 410	144B105	Texas Instrument 928/also HP
61B101	Tandem 6526	398A103	Texas Instrument 931
841B107	Tandem 6528 (European)	190A105	Texas Instrument 940
633A106	Tandem 6530	283A108	Texas Instrument 5130
70C106	Tandem TS-530(also Hitek.Adds)	35B101	Texas Microsystems (also ALR, Easy Data, Maxiswitch, Everex,Gateway,Opus,Avtech)
387C105	Tandem G80-1191-HBU (also Cherry)	672B101	Texas Instrument 386/33 (also AST)
367B101	Tandon RT-101A (also Hitek)	73B101	Texas Instrument 101A(also Acer,Nec, Multitech,Cannon,Stone Systems, Data General,Delta Gold)
85B102	Tandon Enhanced 101	702C83	Texas Instrument Travelmate 4000E FCC:A9248625E
714B102	Tandon/Cherry G80-1251-SAD (European)	460D85	Texas Instrument Extensa 450T Fcc:HLZEXTENSA
200C106	Tandon/Cherry G80-1207-HAD/04(Euro)	658D86	Texas Instrument Travelmate 7100 Laptop(also Acer)
*****	TANDY ALL MODELS SEE RADIO SHACK	514E17	Thales Artema P4432-052
664D104	Tangent 6511-M Fcc:JVP6511M (also Acer)	534D113	Tip-Pro 5160 M2000 #16380
258E107	Tangent 5126T, Fcc: EXKB5126TH0610 (also BTC)	88B82	Toshiba T-1000
234B93	Tascom 93 Switch	279C82	Toshiba T1000 XE/SE-1200XE
651B107	Tatung 107 Keys	550B81	Toshiba 1100(+)
529B102	Tatung TCS 8120S (also Btc,KLH,Goldstar, Packard Bell,Mitsuma,Hewitt Rand)	838A82	Toshiba T-1200
438B101	Tatung FKB4700(also Data General, Dasher,Earthstation,Emerson,Sanyo, Vendex, Fujitsu)	377C84	Toshiba T-1800 (Euro) ALL Euro 1800 & 1900 SERIES
684B102	TB 102G (European)	794C85	Toshiba T-2400 (EURO)
932E94	TCW Q500 15" notebook	859C85	Toshiba "SATELLYTE"(EURO)w/trackpoint
358B105	Tektronix 105 Switch	541C82	Toshiba T-1850/1900-200 FCC:CJ6UK190 U.S. ALL 1800 & 1900 SERIES
231A102	Tektronix 4107/4109	928A81	Toshiba 3100-20
824A86	Tektronix 4205/4207	280C86	Toshiba T3100SX
354C101	Tektronix 101wn63S-45E(also Dec, Honeywell)	549B85	Toshiba T-3200
177C105	Tektronix VT-220 (also Liberty,Hitek)	533B92	Toshiba 5200 (European)/T3200SX
505B114	Teledesk TD1600 HAC	453C91	Toshiba 5200/100
618D101	Telemex EAT1010P2 Fcc:GJEAT1010BR (also SeJin)	378C102	Toshiba T-6400
605D87	Telepad Portable w/ Touchpad	974C85	Toshiba Satelite T2100/260 21XX/2100 2115/2130/2135/2150/2155/2130CS FCC:CJ6UK727
288B106	Teleray 200HP	879C83	Toshiba T2400CS/250 w/trackpoint (US VERSION) FCC:CJ6UK273
195E105	Television GP101DB, Fcc:FBX5E9GP101, Rec enter	81D83	Toshiba Tecra 700CT/CS
748B120	Telescan II	82D83	Toshiba Protege 3400/3600/3600CT/610CT
499A88	Teletype Model 40	92D82	Toshiba T-4700CT/200 FCC:CJ6UK454
124A67	Teletype Model 43	101D82	Toshiba 110CS/110CT/115CS/200CDS/205CDS/410 410CDS/415CS/420/425/430/435CDS/REC ENTER
164A80	Televideo 910/912	102D82	Toshiba 100/100CS/100CT/105/105CS/400/400CS 400CDT/405 RECT. ENTER
04B111	Televideo 970	112D104	Toshiba Desktop 7130/7160/7200 Fcc:CIGEO6100Z (also Keytronics)
603A75	Televideo Personal Terminal	233D85	Toshiba Tecra 500CS/500CDT/trackpoint
393D85	Toshiba 220CDS/225CDS/305/310/315/320/325 445CDT/445CDX/465CDT/465CDX PA1240UVCD		

P/N	Description	P/N	Description
234D87	Toshiba Protege 300CT/650CT trackpoint	318E107	Unicomp M-13 P/N UNI04G6 (also IBM)
235D85	Toshiba 710/720/720CT/730 w/trackpoint	1802B104	Unicomp 104DYW69-53
287D104	Toshiba EO6150US0002C FCC:CIGEO6100Z wristrest builtin (also Keytronics)	691B94	Unisys F4725-25 (VT1120)
557D87	Toshiba 520CDT/750CDT W/ Trackpoint	752B101	Unisys Postal Keyboard(US)
581D80	Toshiba Libretto 50CT/70CT/810	89B101	Unisys 101/E03443 (also Keytronics,Dec)
604D88	Toshiba 460CDX/2 Satellite Pro (Euro)	241B110	Unisys B25 K-2
614D87	Toshiba 530CDT	258B113	Unisys T27 K-5
648D84	Toshiba Libretto 100CT/2.1 (Euro)	151B105	Unisys F4862
670D87	Toshiba Tecra 8000 Port.	322B105	Unisys F5197-00
709D87	Toshiba 330CDS/4000CDS/4010CT,4010CDT PA1273U-S2C	771B101	Unisys PW2
721D118	Toshiba KB9805 Multimedia (also Chicony)	579B105	Unisys TO300 (Euro)(also Link)
844D87	Toshiba Satellite 1555CDS, 2100CDS, 2590CDT, 2060CDS,4100XDVD,4030 Model# PAS206U-A With Trackpoint, Win Keys, Speakers, 2-buttons Over Trackpad	137C98	Unisys B-21-512
845D85	Toshiba Satellite 4030 Rec enter, win keys, speakers, trackpoint	801C112	Unisys B-39/B-28/K-5
16E90	Toshiba Tecra 8100, 2805, M/N PT810U, Rec enter	132D105	Unisys PCK104-SKB (EURO) Fcc: E8HKB5323 (also Chicony)
34E89	Toshiba Satellite 1625CDT, PS162U-48986, Trackpoint	403B101	Unisys PCK-101-KBD KPQE99YC Fcc:EW4KPQ2479D
42E90	Toshiba Satellite 2210CDT,2250XCDS 4260,2670DVD PS221U-490J0, PS225U-M91J08	516D105	Unisys 105DYW76-596, KB6001, Fcc:J25104DLY (euro)
113E90	Toshiba Satellite 4320, 4310XCDDT, M/N XS432P604L8B	538D104	Unisys PCK104SKB Fcc: CMYKPQ7615/KPQE99ZC13 (Rect. Enter)
219E82	Toshiba 2800-S202, P/N PS280U-00 13NB	584D105	Unisys PCK104-SKB (Euro) Fcc:CMYKPQE99ZC13
234E99	Toshiba 1800-S203, P/n PS181U00CFC2E, Toshiba 1805	291E104	Unitech K2726, C/C reader, back-L enter (also Acekey)
302E90	Toshiba #6000, trackpoint, rec enter	517E105	Unitech K2724S/ACK720 (Euro) (also Acekey)
325E91	Toshiba Satellite 1200-S121, Glidepoint	571E102	Unitech KP3800, Fcc: KP3800T2PWE
432E89	Toshiba Tecra Laptop with trackpoint and Glidepoint	572E104	Unitech KP3700, Fcc: KP3700T2PWE
706E91	Tranz 2000/Bilink N7 Portable	725B101	Unitek K-158/258 (also Magnatronics)
378D105	Trogon TG-8200 Laptop W/ touchpad,Win Keys	726B101	Unitek K-159 (also Magnatronics)
595D88	Trogon Model GREEN 735 Laptop	727B101	Unitek K-160/K-260 (also Digicom, Minta)
714D92	Trogon Model GREEN 759 Laptop	820A84	Unitek K-150 (DAH YANG)
849D89	Trogon Model#MP993 W/ glidepoint	951A101	Unitek K-156/256 (DAH YANG)
901D90	Trogon Model B20KBD W/win, "7" enter	86C101	Unitek K-251 (DAH YANG)
957D90	Trogon No #'s Rec enter, glidepoint, win keys	870B101	Unitek K-256(also Nantan,NTC)
981D89	Tulip SR9151B FCC:FPW9151B (Euro)	43C102	Unitek K-261(EURO, S.A.)
381D105	TURBO-JET see HQK	314C102	Unitek K-258 (Dah Yang)
XXXXXXX	TurboKitty Keyboard	402C101	Unitek K-258CM FCC:FMAKB6551(Also NTC)
518E108	Triad G80-3314-HAU(also Cherry)	315C102	Unitek K-260/K-261 (U.S.)
338C105	Triad 101329(KB85) (also Wyse,Link)	791C101	Unitek K-270
618A105	Triad P/N 900244-67 (also Wyse,Link)	268C80	Unitek UTA portable laptop
817D105	Trigem SKR-1032 (also Sejin,Radio Shack,AST)	789C85	Unitek ACK-500 Mini(also Acekey)
254C101	True Basix TXT3500	790C101	Unitek ACK-200 FCC:H2UACEKEY002(also Acekey)
811E125	True Basix TXT2700	791C101	Unitek FCC:L2BACEKEY700 (also Acekey)
887E117	Truebasix TXT-2500 (Euro)	114D101	Unitek K2724 w/credit card reader
780E117	Truebasix TXT-2200 (Euro)	802A101	US 101 (also Keytronics,AT&T,Samsung, Dell, Rita, Arnet)
781E108	Truebasix TXT-2800 (Euro)	229C101	US 101 DS-1000 FCC:H77DS101-3000MS
782E126	Truetouch P/N 154796, Multimedia, Hot Keys	970C104	US Logic SK110CW GYUR26SK (also LITE-ON)
68E123	Truetouch P/N 154758 Fcc:IZITK105M (also Professional)	160B84	Vendex Headstart (also Hitek)
69E126	Tulip ATK030249 (European)	438B101	Vendex Headstart XT FKB4700 (also Data Gen,Dasher, Fujitsu, Earthstation,Emerson,Sanyo,Tatung)
447B102	Tulip 9151B, Fcc:FPW9151B-68W, P/N 11-500001-00	107C79	Veridata Turbolite 110 Port.(Euro)
995D104	TwinHead 101KB6251(also BSC,Magitronics Zeos,Nan Tan,NTC,Premier,Dataware,Wang)	458C80	Veridata Execulite 386S/25e
592D88	Twinhead Slimnote 8 MCT-2000 Laptop	573D81	Versa Point Wireless VP6200 W/Glidepoint
789D109	Twinpath KB9000(E) Fcc:LFCACEKEY1 (also Acekey)	512B102	Versys 102 Key(3 Lights)
191D118	Type 5 ModelS5-100 FCC:K6XS500	774B101	Versys RT-101+ (also Ast,Hitek)
49E111	Ultimate Technology M531	256B102	Victor 102
55E120	Ultimate Technology M630	471B102	Victor/102 Microswitch (European)
626E69	Ultimate Technology M531, p/n CO9285	242B113	Videcom 113 Switch
217C85	Ultra 386SX-20mhz Port.(also Chicony, Epsom) Portable	337B122	Videcom 122 Switch
565C101	Ultra SK2000R FCC:GYUR10SK "L" shaped Enter (also Liteon,Elite,Hewitt Rand,Zenith)	843E117	Viewsonic KU206 VSACC27936-1M
761C101	Ultra KB 5331 FCC:E8HKB-5311(also Chicony)	742B106	Visa 33 (European)
64D103	Ultra 103 FCC:BITS 6001	202B108	Visentech System 230
270D107	Ulysse 600 (Euro)port	919B113	Visentech System T227
675D104	Unicomp 104DYW66-485 Fcc:J2S104DLY (also Linkworld)	706B63	Viskase 63 Key
842D84	V-Tech Wizard 2.0	952A80	Visual 60
		946A106	Visual 241
		94C95	Visual 383
		136C108	Visual 108 Switch
		137A94	Volker Craig 94 Switch
		619C114	VS-211KB
		841D88	V-Tech Equalizer Laptop W/ Mouse
		169B104	Wang PC 280
		155B105	Wang 2110/2110A

P/N	Description	P/N	Description
90B101	Wang 4230/4230A	329E104	Wyse KU-8933, 901716 (also Microsoft)
839A101	Wang PC/4250/Professional	505E104	Wyse 7932M, rec enter, (also BTC)
156B109	Wang 724-3770 PC200/300/724	889E105	Wyse KU8933 p/n 901715-34 A7" enter
225B105	Wang 723 PC200/300/723	111A76	Xerox 820-6060 Series
626B104	Wang 720(725-8073)	930C85	Xtrapro portable
478B106	Wang 4205 VS-I (European)	651A95	Zenith 100/120
10B101	Wang 310/7257660 (also Honeywell, Microswitch)	454A84	Zenith 148/150/151/152/248
117C101	Wang 725-7943 (see#725-6927) GS23TYCSK1101S	290B101	Zenith 101 Enhanced
442B101	Wang MEC-101S (also NTC, Dataware BSC, NanTan Twinhead, Premier, Magitronics)	189B78	Zenith Supersport PC/184
598E88	Wasp Technologies WKB-1000, winsows, C/C Reader	594B79	Zenith Supersport 286
940C101	Wave N860-8720-T301(also Fujitsu)	284C80	Zenith Minisport ZL2
252B84	Wedge Microstation II	281C81	Zenith Mastersport 386SX
994A101	Wells American RT(also Earthstation, Hitek, Televideo)	403C82	Zenith Mastersport 386SL-60 modelZWL-320-06 Fcc: IFO STINGRAY
04E101	Westrex International KBW2400, "L" enter	565C101	Zenith SK2000RE FCC:GYUR10SK "L"Shaped Enter (also Liteon, Ultra, Elite, Hewitt Rand)
349E108	Win98 keyboard (also Linkworld), rounded keys,	356C82	Zenith Z note Portable 325LC PS235
508D104	Winbest Turbojet KB8801R+ (also HQK)	835C85	Zenith Z-note FLEX NT B005 FCC:IFO-NT0005 M/N UBC-0043-00
856C85	Winbook XP Portable w/trackball	601A63	Zenith 171
857C85	Winbook XP portable w/trackpoint & touchpad	383C101	Zenith IB-10 FCC:GJK-101WN-5(also Honeywell)
788D89	Winbook XL W/ Win keys, Glidepoint	411C101	Zenith ZKB-3 101RX43S-72e FCC:GJK101RX-5 (also Honeywell)
150E118	Wincor Nixdorf /Siemens POS Computer w/Flat keys	561C102	Zenith 102WN63S-7EN(EURO) (also Honeywell) Fcc:GJK101WN5
245D88	Wintek ACK-595 (also Acekey)	986C101	Zenith KB-5323 FCC:EH8KB5323 (also Chicony)
886E90	Wireless Computing RF220 compact keyboard Fcc:L7MR220	833C85	Zenith Z-Star notebook 433VLP (also Pack Bell)
885E107	Wireless Computing RF250 Fcc: L7MR250	151D102	Zenith KB5323 w/windows (EURO)(also Chicony)
590B125	Wisconsin Bell Keyboard	325C84	Zentec ADM11 full keys(also Lear Siegler)
643D89	Wombat SPR8697/WV6 Wireless (Euro) (also SeJin)	733A103	Zentec Series 1000
656D139	Wombat SKI1292 (also Keysource)	162B107	Zentec ADM 12(+)
657D159	Wombat SKI1290A (also Keysource)	52B86	Zentec Technicon T2201
804D103	Wombat Wizard SKR1196WT6A/KSI 2196	51B88	Zentec Technicon 4201
805D160	Wombat KSI1290 W/ CC Reader	263B108	Zentec 8392
573E160	Wombat KSI1290-A (also Keysource Int=I.)	442B101	Zeos RS (also Nan Tan, NTC, BSC, Magitronics Twin Head, Premier, Dataware, Wang)
501E86	Wombat Wireless FDC3402, rec enter (also Microslate)	443B101	Zeos Model F12 (also Nan Tan, NTC)
896E159	Wombat KSY1390NBC	38C82	Zeos Notebook Portable(also Everex)
565A83	Wyse 30 840013-01, 900023-08	749E90	Zippy WK-620
385A101	Wyse 50/75/350/840059 (also Altos, Radio Shack)	768E104	Zippy WK-720
179D102	Wyse 55 #841135-01	517C95	Zorba Telecon Keyboard
391B103	Wyse 60 (103 Switch Euro)840362-01 (Raised above function keys)	872E58	Zygo Polyana Laptop
840A101	Wyse 60/160 ASCII/ANSI/150(also Altos) #840338-01		
727A84	Wyse 60AT		
841A102	Wyse 60 PC 286/386 Enh (3 lights) model #840358-1(also Amdek, Arnet) (raised above Function Keys)(3 raised LEDS) J6GKTIC-KB-M102		
692B102	Wyse 60/900840-1(also Link, Alpha Micro) (Flat Above Function Keys)(3 raised LEDS) #840358-30, 50-120-000-102,900866-01		
657C103	Wyse 60 (EURO) Flat above "F" keys		
618A105	Wyse 85 840366-1 (also Link, Triad)		
579B105	Wyse 185		
527C108	Wyse 285 ANSI 901028-01		
572A83	Wyse 1100		
348D101	Wyse 901857-01, 901867-01, ASCII,909073-01		
368D104	Wyse Winterm FCC:CIGEO6100Z (also Keytronics)		
160D104	Wyse 901861-26, Winterm, KB8923 (also IBM)		
353D102	Wyse 901865-99 EPC		
817D105	Wyse P/N 900244-67 (also Link Triad)		
285E101	Wyse ASCII, 598-0011717, rec enter (also Adds)		